

MODEL PARTS

B25A02Z

Part #	Description
014-12296-17	CABINET FRONT, TV, MOLDED PLASTIC
014-12297-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
024-03372	COVER, BLANK, 2 X 5 SPEAKER OPENING
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
050-02576-08	CONNECTOR AND CABLE ASSEMBLY
095-04456-06	TRANSFORMER, DEFLECTION, YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00213-23	SPACE COMMAND TRANSMITTER, TV ONLY SC3492Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00916	LENS, IR
206-03551	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
A-18681-01	LINE CORD ASSY WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B25A10Z, B25A10ZC, B25A10Z6, B25A10ZC6

Part #	Description
014-12296-17	CABINET FRONT, TV, MOLDED PLASTIC
014-12297-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04456-06	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00213-23	SPACE COMMAND, TRANSMITTER, TV ONLY SC3492Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00916	LENS, IR
206-03476	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
A-18681-01	LINE CORD ASSY WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B25A10ZCF

Part #	Description
014-12296-17	CABINET FRONT, TV, MOLDED PLASTIC
014-12297-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04456-06	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00213-23	SPACE COMMAND, TRANSMITTER, TV ONLY SC3492Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00916	LENS, IR
206-03476	INSTR BOOK, OPERATION GUIDE

206-03557	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B25A11Z, B25A11Z6

Part #	Description
014-12296-17	CABINET FRONT, TV, MOLDED PLASTIC
014-12297-09	CABINET REAR, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04456-06	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00916	LENS, IR
206-03477	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B25A11ZF

Part #	Description
014-12296-17	CABINET FRONT, TV, MOLDED PLASTIC
014-12297-09	CABINET REAR, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04456-06	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00916	LENS, IR
206-03477	INSTR BOOK, OPERATION GUIDE
206-03556	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B25A24Z, B25A24Z6

Part #	Description
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12143-02	CABINET TRAY, MOLDED PLASTIC
014-12181-09	CABINET REAR, TV, MOLDED PLASTIC
014-12187-14	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10554	KNOB ARRAY, PUSH-BUTTON, 10 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04456-06	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL

MODEL PARTS (Continued)

A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00858-01	LENS, PRIMARY CONTROLS AND IR
194-02535	PAD, PUSHBUTTONS
206-03479	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
F-50826	KEYBOARD ASSY, WITH IR RECEIVER, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B25A24ZF

Part #	Description
014-12143-02	CABINET TRAY, MOLDED PLASTIC
014-12181-09	CABINET REAR, TV, MOLDED PLASTIC
014-12187-14	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10554	KNOB ARRAY, PUSH-BUTTON, 10 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04456-06	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00858-01	LENS, PRIMARY CONTROLS AND IR
194-02535	PAD, PUSHBUTTONS
206-03479	INSTR BOOK, OPERATION GUIDE
206-03555	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
F-50826	KEYBOARD ASSY, WITH IR RECEIVER, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B25A30ZC

Part #	Description
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12038-02	CABINET TRAY, TV, MOLDED PLASTIC
014-12229-17	CABINET FRONT, TV, MOLDED PLASTIC
014-12230-03	CABINET REAR, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10561	KNOB ARRAY, PUSH BUTTON, 10 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04456-06	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00887	LENS, INFRARED
194-02535-01	PAD, PUSHBUTTONS
206-03480	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY

F-50825	KEYBOARD ASSY, WITH IR RECEIVER, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B25A30ZCF

Part #	Description
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12038-02	CABINET TRAY, TV, MOLDED PLASTIC
014-12229-17	CABINET FRONT, TV, MOLDED PLASTIC
014-12230-03	CABINET REAR, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10561	KNOB ARRAY, PUSH BUTTON, 10 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04456-06	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
101-08795	LABEL, BLANK, WHITE
112-00932-01	SCREW, THD CUT, 4-24 X 0.312 TP BT BP, PAN HEAD, PHILLIPS
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00887	LENS, INFRARED
194-02535-01	PAD, PUSHBUTTONS
206-03480	INSTR BOOK, OPERATION GUIDE
206-03554	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
F-50825	KEYBOARD ASSY, WITH IR RECEIVER, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B25A74R

Part #	Description
002-04084-11	CABINET BACK, PRESSED WOOD
012-10810-01	MOLDED PLASTIC, PANEL, JACK PACK, GA CHASSIS
014-12191-03	CABINET MAIN, TV, WOOD
020-04330-35	COIL, DEGAUSSER
030-01455-14	DECORATIVE ITEM, CABINET HARDWARE
046-10555	KNOB ARRAY, PUSH-BUTTON, 10 POSITIONS, STR
049-01302-03	SPEAKER, OVAL, 3X5 INCH
057-09067-09	ESCUTCHEON, TV, MOLDED PLASTIC
095-04456-05	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00876	CRYSTAL WINDOW, IR
194-02535	PAD, PUSHBUTTONS
206-03450	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
F-50961	KEYBOARD ASSY, WITH IR, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

MODEL PARTS (Continued)

B25A74LK

Part #	Description
002-04084-11	CABINET, BACK, PRESSED WOOD
012-10810-01	MOLDED PLASTIC, PANEL, JACK PACK, GA CHASSIS
014-12191-05	CABINET, MAIN
020-04330-35	COIL, DEGAUSSER
030-01455-14	DECORATIVE ITEM, CABINET HARDWARE
046-10555	KNOB ARRAY, PUSH-BUTTON, 10 POSITIONS, STR
049-01302-03	SPEAKER, OVAL, 3X5 INCH
057-09067-09	ESCUTCHEON, TV, MOLDED PLASTIC
095-04456-05	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00876	CRYSTAL WINDOW, IR
194-02535	PAD, PUSHBUTTONS
206-03450	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
F-50961	KEYBOARD ASSY, WITH IR, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B25A76R5

002-04103-01	CABINET BACK/ /
014-11639-19	CABINET REAR/ TV, MOLDED PLASTIC/
014-12333	CABINET MAIN/ TV, WOOD/
020-04330-35	COIL/ DEGAUSSER/
040-00567	HINGE/ /
049-01302-03	SPEAKER/ OVAL/ 3X5 INCH
057-09067-08	ESCUTCHEON/ TV, MOLDED PLASTIC/
100-00812-05	VACUUM TUBE/ CRT, COLOR, 25 INCH DIAGONAL/
110-00687-59	GRILLE CLOTH/ RECTANGULAR/
152-00335	WEDGE/ YOKE SPACER/POSITIONER/
192-00876	CRYSTAL WINDOW / IR/
192-00892	GLASS DOOR/ /
206-03450	INSTR BOOK/ OPERATION GUIDE/
A-07690-06	MAGNET ASSEMBLY/ STATIC CONVERGENCE AND PURITY/

CB25A25Z, CB25A25Z6

Part #	Description
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12038-02	CABINET TRAY, TV, MOLDED PLASTIC
014-12229-17	CABINET FRONT, TV, MOLDED PLASTIC
014-12230-03	CABINET REAR, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10561	KNOB ARRAY, PUSH BUTTON, 10 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04456-06	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00887	LENS, INFRARED
194-02535-01	PAD, PUSHBUTTONS
206-03479	INSTR BOOK, OPERATION GUIDE

A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
F-50825	KEYBOARD ASSY, WITH IR RECEIVER, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

LGB26A11ZM, LGB26A11ZM6

Part #	Description
014-12296-17	CABINET FRONT, TV, MOLDED PLASTIC
014-12297-09	CABINET REAR, TV, MOLDED PLASTIC
020-04330-42	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04456-06	TRANSFORMER, DEFLECTION YOKE, 25V HIBI COMERCIAL
A63AFW38X	VACUUM TUBE, CRT, COLOR, 25 INCH DIAGONAL
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
192-00916	LENS, IR
206-03494	INSTR BOOK, OPERATION GUIDE
A-07690-06	MAGNET ASSEMBLY, STATIC CONVERGENCE AND PURITY
A-14323	BALUN ASSEMBLY,
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

B27A10Z, B27A10Z6, B27A10ZC, B27A10ZC6

Part #	Description
014-12304-03	CABINET REAR, TV, MOLDED PLASTIC
014-12305-08	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00213-23	SPACE COMMAND, TRANSMITTER, TV ONLY SC3492Z
192-00916	LENS, IR
206-03476	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-03	CRT AND YOKE, ASSEMBLY, 27V

B27A10Z5, B27A10ZC5

Part #	Description
014-12304-03	CABINET REAR, TV, MOLDED PLASTIC
014-12305-08	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00213-23	SPACE COMMAND TRANSMITTER, TV ONLY SC3492Z
192-00916	LENS, IR
206-03476	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-01	CRT AND YOKE, ASSEMBLY

MODEL PARTS (Continued)

B27A10ZCF

Part #	Description
014-12304-03	CABINET REAR, TV, MOLDED PLASTIC
014-12305-08	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00213-23	SPACE COMMAND, TRANSMITTER, TV ONLY SC3492Z
192-00916	LENS, IR
206-03476	INSTR BOOK, OPERATION GUIDE
206-03557	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-03	CRT AND YOKE, ASSEMBLY, 27V

B27A11Z, B27A11Z6, B27A11ZC

Part #	Description
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12281-08	CABINET FRONT, TV, MOLDED PLASTIC
014-12282-06	CABINET REAR, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10588	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
192-00912	LENS, PRIMARY CONTROLS AND IR
194-02663	PAD, PUSHBUTTONS
206-03477	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-52954	KEYBOARD ASSY, 6 BUTTON, 27V GA CHASSIS
A-19058-03	CRT AND YOKE, ASSEMBLY, 27V

B27A11Z5, B27A11Z65, B27A11ZC5

Part #	Description
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12281-08	CABINET FRONT, TV, MOLDED PLASTIC
014-12282-06	CABINET REAR, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10588	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
192-00912	LENS, PRIMARY CONTROLS AND IR
194-02663	PAD, PUSHBUTTONS
206-03477	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-52954	KEYBOARD ASSY, 6 BUTTON, 27V GA CHASSIS
A-19058-01	CRT AND YOKE, ASSEMBLY

B27A24Z, B27A24Z6

Part #	Description
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12254-06	CABINET REAR, TV, MOLDED PLASTIC
014-12317-04	CABINET FRONT, TV, MOLDED PLASTIC

020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10589	KNOB ARRAY, PUSH-BUTTON, 6 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
138-01964-02	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, LEFT SIDE
138-01964-03	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, RIGHT SIDE
192-00923	LENS, IR
194-02665	PAD, PUSHBUTTONS
206-03479	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-53039	KEYBOARD ASSY, 6 BUTTON, 27V GB CHASSIS
A-19058-03	CRT AND YOKE, ASSEMBLY, 27V

B27A24Z5, B27A24Z65

Part #	Description
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12254-06	CABINET REAR, TV, MOLDED PLASTIC
014-12317-04	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10589	KNOB ARRAY, PUSH-BUTTON, 6 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
138-01964-02	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, LEFT SIDE
138-01964-03	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, RIGHT SIDE
192-00923	LENS, IR
194-02665	PAD, PUSHBUTTONS
206-03479	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-53039	KEYBOARD ASSY, 6 BUTTON, 27V GB CHASSIS
A-19058-01	CRT AND YOKE, ASSEMBLY

B27A24ZF

Part #	Description
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12254-06	CABINET REAR, TV, MOLDED PLASTIC
014-12317-04	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10589	KNOB ARRAY, PUSH-BUTTON, 6 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
138-01964-02	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, LEFT SIDE
138-01964-03	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, RIGHT SIDE
192-00923	LENS, IR
194-02665	PAD, PUSHBUTTONS
206-03479	INSTR BOOK, OPERATION GUIDE
206-03555	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT

MODEL PARTS (Continued)

F-53039 KEYBOARD ASSY, 6 BUTTON, 27V GB CHASSIS
 A-19058-03 CRT AND YOKE, ASSEMBLY, 27V

B27A24ZF5

Part #	Description
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12254-06	CABINET REAR, TV, MOLDED PLASTIC
014-12317-04	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10589	KNOB ARRAY, PUSH-BUTTON, 6 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
138-01964-02	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, LEFT SIDE
138-01964-03	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, RIGHT SIDE
192-00923	LENS, IR
194-02665	PAD, PUSHBUTTONS
206-03479	INSTR BOOK, OPERATION GUIDE
206-03555	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-53039	KEYBOARD ASSY, 6 BUTTON, 27V GB CHASSIS
A-19058-01	CRT AND YOKE, ASSEMBLY

B27A30Z, B27A30ZC, B27A30ZC6

Part #	Description
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12281-08	CABINET FRONT, TV, MOLDED PLASTIC
014-12282-06	CABINET REAR, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10588	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
192-00912	LENS, PRIMARY CONTROLS AND IR
194-02663	PAD, PUSHBUTTONS
206-03480	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-52954	KEYBOARD ASSY, 6 BUTTON, 27V GA CHASSIS
A-19058-03	CRT AND YOKE, ASSEMBLY, 27V

B27A30ZC5, B27A30ZC65

Part #	Description
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12281-08	CABINET FRONT, TV, MOLDED PLASTIC
014-12282-06	CABINET REAR, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10588	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
192-00912	LENS, PRIMARY CONTROLS AND IR
194-02663	PAD, PUSHBUTTONS
206-03480	INSTR BOOK, OPERATION GUIDE

A-18681-01 LINE CORD ASSY, WITH YEONHO CONNECTOR
 A-18695-02 GND STRAP ASSY, CRT
 F-52954 KEYBOARD ASSY, 6 BUTTON, 27V GA CHASSIS
 A-19058-01 CRT AND YOKE, ASSEMBLY

B27A30ZCF

Part #	Description
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12281-08	CABINET FRONT, TV, MOLDED PLASTIC
014-12282-06	CABINET REAR, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10588	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
192-00912	LENS, PRIMARY CONTROLS AND IR
194-02663	PAD, PUSHBUTTONS
206-03480	INSTR BOOK, OPERATION GUIDE
206-03554	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-52954	KEYBOARD ASSY, 6 BUTTON, 27V GA CHASSIS
A-19058-03	CRT AND YOKE, ASSEMBLY, 27V

B27A30ZCF5

Part #	Description
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12281-08	CABINET FRONT, TV, MOLDED PLASTIC
014-12282-06	CABINET REAR, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10588	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
192-00912	LENS, PRIMARY CONTROLS AND IR
194-02663	PAD, PUSHBUTTONS
206-03480	INSTR BOOK, OPERATION GUIDE
206-03554	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-52954	KEYBOARD ASSY, 6 BUTTON, 27V GA CHASSIS
A-19058-01	CRT AND YOKE, ASSEMBLY

B27A34Z, B27A34Z6

Part #	Description
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12254-06	CABINET REAR, TV, MOLDED PLASTIC
014-12347	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10589	KNOB ARRAY, PUSH-BUTTON, 6 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233-01	SPACE COMMAND, TRANSMITTER, MBR3457Z
138-01965	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, LEFT SIDE
138-01965-01	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, LEFT SIDE

MODEL PARTS (Continued)

192-00923	LENS, IR
194-02665	PAD, PUSHBUTTONS
206-03481	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-21	GND STRAP ASSY, CRT
F-53039	KEYBOARD ASSY, 6 BUTTON, 27V GB CHASSIS
A-19112	CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 27V 1.7R

B27A34ZF

Part #	Description
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12254-06	CABINET REAR, TV, MOLDED PLASTIC
014-12347	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10589	KNOB ARRAY, PUSH-BUTTON, 6 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233-01	SPACE COMMAND, TRANSMITTER, MBR3457Z
138-01965	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, LEFT SIDE
138-01965-01	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, LEFT SIDE
192-00923	LENS, IR
194-02665	PAD, PUSHBUTTONS
206-03481	INSTR BOOK, OPERATION GUIDE
206-03553	INSTR BOOK, OPERATION GUIDE
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-21	GND STRAP ASSY, CRT
F-53039	KEYBOARD ASSY, 6 BUTTON, 27V GB CHASSIS
A-19112	CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 27V 1.7R

B27A74R

Part #	Description
002-04084-13	CABINET BACK, PRESSED WOOD
012-10810-01	MOLDED PLASTIC, PANEL, JACK PACK, GA CHASSIS
014-12326	CABINET MAIN, TV, WOOD
020-04330-30	COIL, DEGAUSSER
030-01455-09	DECORATIVE ITEM, CABINET HARDWARE
046-10555	KNOB ARRAY, PUSH-BUTTON, 10 POSITIONS, STR
049-01334-02	SPEAKER, OVAL, 3X6.500
057-09055-43	ESCUTCHEON, CRT
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
192-00872	CRYSTAL WINDOW, IR, STEREO, AND COLOR SENTRY
194-02535	PAD, PUSHBUTTONS
197-00180-01	CUP, CABINET BACK
206-03372	INSTR BOOK, OPERATION GUIDE
F-50961	KEYBOARD ASSY, WITH IR, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-03	CRT AND YOKE ASSEMBLY

B27A74R5

Part #	Description
002-04084-13	CABINET BACK, PRESSED WOOD
012-10810-01	MOLDED PLASTIC, PANEL, JACK PACK, GA CHASSIS
014-12326	CABINET MAIN, TV, WOOD

020-04330-30	COIL, DEGAUSSER
030-01455-09	DECORATIVE ITEM, CABINET HARDWARE
046-10555	KNOB ARRAY, PUSH-BUTTON, 10 POSITIONS, STR
049-01334-02	SPEAKER, OVAL, 3X6.500
057-09055-43	ESCUTCHEON, CRT
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
192-00872	CRYSTAL WINDOW, IR, STEREO, AND COLOR SENTRY
194-02535	PAD, PUSHBUTTONS
197-00180-01	CUP, CABINET BACK
206-03372	INSTR BOOK, OPERATION GUIDE
F-50961	KEYBOARD ASSY, WITH IR, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-01	CRT AND YOKE ASSEMBLY

B27A76R

Part #	Description
002-04103-02	CABINET BACK,
014-11639-20	CABINET REAR, TV, MOLDED PLASTIC
014-12327	CABINET MAIN, TV, WOOD
020-04330-30	COIL, DEGAUSSER
040-00567	HINGE,
046-10555	KNOB ARRAY, PUSH-BUTTON, 10 POSITIONS, STR
049-01334-02	SPEAKER, OVAL, 3X6.500
057-09055-42	ESCUTCHEON, CRT
110-00687-59	GRILLE CLOTH, RECTANGULAR
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
192-00872	CRYSTAL WINDOW, IR, STEREO, AND COLOR SENTRY
192-00892	GLASS DOOR,
194-02535	PAD, PUSHBUTTONS
206-03372	INSTR BOOK, OPERATION GUIDE
F-50961	KEYBOARD ASSY, WITH IR, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-03	CRT AND YOKE ASSEMBLY

B27A76R5

Part #	Description
002-04103-02	CABINET BACK,
014-11639-20	CABINET REAR, TV, MOLDED PLASTIC
014-12327	CABINET MAIN, TV, WOOD
020-04330-30	COIL, DEGAUSSER
040-00567	HINGE,
046-10555	KNOB ARRAY, PUSH-BUTTON, 10 POSITIONS, STR
049-01334-02	SPEAKER, OVAL, 3X6.500
057-09055-42	ESCUTCHEON, CRT
110-00687-59	GRILLE CLOTH, RECTANGULAR
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
192-00872	CRYSTAL WINDOW, IR, STEREO, AND COLOR SENTRY
192-00892	GLASS DOOR,
194-02535	PAD, PUSHBUTTONS
206-03372	INSTR BOOK, OPERATION GUIDE
F-50961	KEYBOARD ASSY, WITH IR, AGUA CHASSIS
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-01	CRT AND YOKE ASSEMBLY

MODEL PARTS (Continued)

LGB29A10ZM

Part #	Description
014-12304-03	CABINET REAR, TV, MOLDED PLASTIC
014-12305-08	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01526-03	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00213-23	SPACE COMMAND, TRANSMITTER, TV ONLY SC3492Z
192-00916	LENS, IR
206-03495	INSTR BOOK, OPERATION GUIDE
A-14323	BALUN ASSEMBLY,
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-03	CRT AND YOKE, ASSEMBLY, 27V

LGB29A10ZM5

Part#	Description
014-12304-03	CABINET REAR, TV, MOLDED PLASTIC
014-12305-08	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01526-03	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00213-23	SPACE COMMAND TRANSMITTER, TV ONLY, SC3492Z
192-00916	LENS, IR
206-03495	INSTR BOOK, OPERATION GUIDE
A-14323	BALUN ASSEMBLY
A-18681-01	LINE CORD ASSY WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-01	CRT AND YOKE, ASSEMBLY

LGB29A11ZM

Part #	Description
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12281-08	CABINET FRONT, TV, MOLDED PLASTIC
014-12282-06	CABINET REAR, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01526-03	DECORATIVE ITEM, LOGO, ZENITH
046-10588	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
192-00912	LENS, PRIMARY CONTROLS AND IR
194-02663	PAD, PUSHBUTTONS
206-03494	INSTR BOOK, OPERATION GUIDE
A-14323	BALUN ASSEMBLY,
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-52954	KEYBOARD ASSY, 6 BUTTON, 27V GA CHASSIS
A-19058-03	CRT AND YOKE, ASSEMBLY, 27V

LGB29A11ZM5

Part#	Description
012-10858-03	MOLDED PLASTIC PANEL, JACK PACK
014-12281-08	CABINET FRONT, TV, MOLDED PLASTIC
014-12282-06	CABINET REAR, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01526-03	DECORATIVE ITEM, LOGO, ZENITH

049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND TRANSMITTER, MBR3447Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03494	INSTR BOOK, OPERATION GUIDE
A-14323	BALUN ASSEMBLY
A-18681-01	LINE CORD ASSY WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-01	CRT AND YOKE ASSEMBLY
F-52954	KEYBOARD ASSY, 6 KEY

LGB29A13ZM

Part #	Description
014-12304-03	CABINET REAR, TV, MOLDED PLASTIC
014-12305-08	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-30	COIL, DEGAUSSER
030-01526-03	DECORATIVE ITEM, LOGO, ZENITH
046-10578	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00229	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3345Z
192-00916	LENS, IR
206-03498	INSTR BOOK, OPERATION GUIDE
A-14323	BALUN ASSEMBLY,
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-01	CRT AND YOKE, ASSEMBLY

LGB29A24ZM

Part #	Description
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12254-06	CABINET REAR, TV, MOLDED PLASTIC
014-12317-04	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10589	KNOB ARRAY, PUSH-BUTTON, 6 POSITIONS
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
138-01964-02	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, LEFT SIDE
138-01964-03	CABINET GRILLE, CLOTH OVER PLASTIC FRAME, RIGHT SIDE
192-00923	LENS, IR
194-02665	PAD, PUSHBUTTONS
206-03497	INSTR BOOK, OPERATION GUIDE
A-14323	BALUN ASSEMBLY,
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-53039	KEYBOARD ASSY, 6 BUTTON, 27V GB CHASSIS
A-19058-03	CRT AND YOKE, ASSEMBLY, 27V

LGB29A24ZM5

Part #	Description
012-10858-04	MOLDED PLASTIC PANEL, JACK PACK
014-12254-06	CABINET REAR, TV, MOLDED PLASTIC
014-12317-04	CABINET FRONT, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND TRANSMITTER, MBR3447Z

MODEL PARTS (Continued)

138-01964-02	CABINET GRILLE, CLOTH OVER PLASTIC, LEFT
138-01964-03	CABINET GRILLE, CLOTH OVER PLASTIC, RIGHT
192-00923	LENS, IR
206-03497	INSTR BOOK, OPERATION GUIDE
A-14323	BALUN ASSEMBLY
A-18681-01	LINE CORD ASSY WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-01	CRT AND YOKE, ASSEMBLY
F-53039	KEYBOARD ASSY, 6 POSITION

LGB29A30ZM

Part #	Description
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12281-08	CABINET FRONT, TV, MOLDED PLASTIC
014-12282-06	CABINET REAR, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
046-10588	KNOB ARRAY, PUSH BUTTON, 6 POSITION
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
192-00912	LENS, PRIMARY CONTROLS AND IR
194-02663	PAD, PUSHBUTTONS
206-03496	INSTR BOOK, OPERATION GUIDE
A-14323	BALUN ASSEMBLY,
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
F-52954	KEYBOARD ASSY, 6 BUTTON, 27V GA CHASSIS
A-19058-03	CRT AND YOKE, ASSEMBLY, 27V

LGB29A30ZM5

Part #	Description
012-10858-03	MOLDED PLASTIC PANEL, JACK PACK
014-12281-08	CABINET FRONT, TV, MOLDED PLASTIC
014-12282-06	CABINET REAR, TV, MOLDED PLASTIC
020-04330-43	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00229-01	SPACE COMMAND TRANSMITTER, BIG BUTTON, MBR3346Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03496	INSTR BOOK, OPERATION GUIDE
A-14323	BALUN ASSEMBLY
A-18681-01	LINE CORD ASSY WITH YEONHO CONNECTOR
A-18695-02	GND STRAP ASSY, CRT
A-19058-01	CRT AND YOKE ASSEMBLY
F-52954	KEYBOARD ASSY, 6 KEY

B32A24Z

Part #	Description
009-02068	MODULE, MAIN, 32V MTSSAP CA CHASSIS, V-CHIP, COMB FILTER
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12284-23	CABINET FRONT, TV, MOLDED PLASTIC
014-12285-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-33	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04517-01	DEFLECTION YOKE, FINAL, COLOR TV, 32V
A81AGZ50X	VACUUM TUBE, CRT,COLOR, 32 INCH DIAGONAL

124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
152-00335-01	WEDGE, CRT SPACER
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03479	INSTR BOOK, OPERATION GUIDE
A-15947-01	BEAM BENDER, ASSEMBLY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-03	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B32A24Z6

Part #	Description
009-02068-01	MODULE, MAIN, 32V MTSSAP CA CHASSIS, V-CHIP, COMB FILTER
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12284-23	CABINET FRONT, TV, MOLDED PLASTIC
014-12285-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-33	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04517-01	DEFLECTION YOKE, FINAL, COLOR TV, 32V
A81AGZ50X	VACUUM TUBE, CRT,COLOR, 32 INCH DIAGONAL
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
152-00335-01	WEDGE, CRT SPACER
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03479	INSTR BOOK, OPERATION GUIDE
A-15947-01	BEAM BENDER, ASSEMBLY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-03	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B32A24ZF

Part #	Description
009-02068	MODULE, MAIN, 32V MTSSAP CA CHASSIS, V-CHIP, COMB FILTER
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12284-23	CABINET FRONT, TV, MOLDED PLASTIC
014-12285-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-33	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04517-01	DEFLECTION YOKE, FINAL, COLOR TV, 32V
A81AGZ50X	VACUUM TUBE, CRT,COLOR, 32 INCH DIAGONAL
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
152-00335-01	WEDGE, CRT SPACER
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03479	INSTR BOOK, OPERATION GUIDE
206-03555	INSTR BOOK, OPERATION GUIDE
A-15947-01	BEAM BENDER, ASSEMBLY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-03	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B32A30Z

Part #	Description
009-02072	MODULE, MAIN, 32V STEREO CA CHASSIS, V-CHIP, PIP, 3 JACKS
009-02107	MODULE, SINGLE PIP, CA CHASSIS

MODEL PARTS (Continued)

012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12284-23	CABINET FRONT, TV, MOLDED PLASTIC
014-12285-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-33	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04208-01	TRANSFORMER, DEFLECTION YOKE, 110 DEGREE
A81AGZ50X	VACUUM TUBE, CRT,COLOR, 32 INCH DIAGONAL
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
152-00335-01	WEDGE, CRT SPACER
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03480	INSTR BOOK, OPERATION GUIDE
A-15947-01	BEAM BENDER, ASSEMBLY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-03	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B32A30Z6

Part #	Description
009-02072-01	MODULE, MAIN, 32V STEREO CA CHASSIS, V-CHIP, PIP, 3 JACKS
009-02107	MODULE, SINGLE PIP, CA CHASSIS
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12284-23	CABINET FRONT, TV, MOLDED PLASTIC
014-12285-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-33	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04208-01	TRANSFORMER, DEFLECTION YOKE, 110 DEGREE
A81AGZ50X	VACUUM TUBE, CRT,COLOR, 32 INCH DIAGONAL
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
152-00335-01	WEDGE, CRT SPACER
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03480	INSTR BOOK, OPERATION GUIDE
A-15947-01	BEAM BENDER, ASSEMBLY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-03	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B32A30ZF

Part #	Description
009-02072	MODULE, MAIN, 32V STEREO CA CHASSIS, V-CHIP, PIP, 3 JACKS
009-02107	MODULE, SINGLE PIP, CA CHASSIS
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12284-23	CABINET FRONT, TV, MOLDED PLASTIC
014-12285-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-33	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04208-01	TRANSFORMER, DEFLECTION YOKE, 110 DEGREE
A81AGZ50X	VACUUM TUBE, CRT,COLOR, 32 INCH DIAGONAL
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
152-00335-01	WEDGE, CRT SPACER

192-00912	LENS, PRIMARY CONTROLS AND IR
206-03480	INSTR BOOK, OPERATION GUIDE
206-03554	INSTR BOOK, OPERATION GUIDE
A-15947-01	BEAM BENDER, ASSEMBLY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-03	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B32A34Z

Part #	Description
009-02075	MODULE, MAIN, 32V MTSSAP CA CHASSIS, V-CHIP,PIP,COMB FILT
009-02107	MODULE, SINGLE PIP, CA CHASSIS
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12284-23	CABINET FRONT, TV, MOLDED PLASTIC
014-12285-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-33	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04208-01	TRANSFORMER, DEFLECTION YOKE, 110 DEGREE
A81AGZ50X	VACUUM TUBE, CRT,COLOR, 32 INCH DIAGONAL
124-00233-01	SPACE COMMAND, TRANSMITTER, MBR3457Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
152-00335-01	WEDGE, CRT SPACER
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03481	INSTR BOOK, OPERATION GUIDE
A-15947-01	BEAM BENDER, ASSEMBLY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-03	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B32A34Z6

Part #	Description
009-02075-01	MODULE, MAIN, 32V MTSSAP CA CHASSIS, V-CHIP,PIP,COMB FILT
009-02107	MODULE, SINGLE PIP, CA CHASSIS
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12284-23	CABINET FRONT, TV, MOLDED PLASTIC
014-12285-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-33	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04208-01	TRANSFORMER, DEFLECTION YOKE, 110 DEGREE
A81AGZ50X	VACUUM TUBE, CRT,COLOR, 32 INCH DIAGONAL
124-00233-01	SPACE COMMAND, TRANSMITTER, MBR3457Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
152-00335-01	WEDGE, CRT SPACER
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03481	INSTR BOOK, OPERATION GUIDE
A-15947-01	BEAM BENDER, ASSEMBLY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-03	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B32A34ZF

Part #	Description
009-02075	MODULE, MAIN, 32V MTSSAP CA CHASSIS, V-CHIP,PIP,COMB FILT
009-02107	MODULE, SINGLE PIP, CA CHASSIS

MODEL PARTS (Continued)

012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12284-23	CABINET FRONT, TV, MOLDED PLASTIC
014-12285-08	CABINET REAR, TV, MOLDED PLASTIC
020-04330-33	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
095-04208-01	TRANSFORMER, DEFLECTION YOKE, 110 DEGREE
A81AGZ50X	VACUUM TUBE, CRT,COLOR, 32 INCH DIAGONAL
124-00233-01	SPACE COMMAND, TRANSMITTER, MBR3457Z
152-00335	WEDGE, YOKE SPACER/POSITIONER
152-00335-01	WEDGE, CRT SPACER
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03481	INSTR BOOK, OPERATION GUIDE
206-03553	INSTR BOOK, OPERATION GUIDE
A-15947-01	BEAM BENDER, ASSEMBLY
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-03	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B36A24Z

Part #	Description
009-02069	MODULE, MAIN, 36V MTSSAP CA CHASSIS, V-CHIP, COMB FILTER
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12269-12	CABINET FRONT, TV, MOLDED PLASTIC, 35V-1R
014-12270-12	CABINET REAR, TV, MOLDED PLASTIC, 3536V
020-04330-34	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03479	INSTR BOOK, OPERATION GUIDE
A-18639	CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 36V CTV
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-04	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B36A24Z6

Part #	Description
009-02069-01	MODULE, MAIN, 36V MTSSAP CA CHASSIS, V-CHIP, COMB FILTER
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12269-12	CABINET FRONT, TV, MOLDED PLASTIC, 35V-1R
014-12270-12	CABINET REAR, TV, MOLDED PLASTIC, 3536V
020-04330-34	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03479	INSTR BOOK, OPERATION GUIDE
A-18639	CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 36V CTV
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-04	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B36A24ZF

Part #	Description
009-02069	MODULE, MAIN, 36V MTSSAP CA CHASSIS, V-CHIP, COMB FILTER
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12269-12	CABINET FRONT, TV, MOLDED PLASTIC, 35V-1R
014-12270-12	CABINET REAR, TV, MOLDED PLASTIC, 3536V
020-04330-34	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233	SPACE COMMAND, TRANSMITTER, MBR3447Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03479	INSTR BOOK, OPERATION GUIDE
206-03553	INSTR BOOK, OPERATION GUIDE
A-18639	CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 36V CTV
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-04	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B36A30Z

Part #	Description
009-02073	MODULE, MAIN, 36V STEREO CA CHASSIS, V-CHIP, PIP, 3 JACKS
009-02107	MODULE, SINGLE PIP, CA CHASSIS
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12269-12	CABINET FRONT, TV, MOLDED PLASTIC, 35V-1R
014-12270-12	CABINET REAR, TV, MOLDED PLASTIC, 3536V
020-04330-34	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03480	INSTR BOOK, OPERATION GUIDE
A-18639	CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 36V CTV
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-04	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B36A30Z6

Part #	Description
009-02073-01	MODULE, MAIN, 36V STEREO CA CHASSIS, V-CHIP, PIP, 3 JACKS
009-02107	MODULE, SINGLE PIP, CA CHASSIS
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12269-12	CABINET FRONT, TV, MOLDED PLASTIC, 35V-1R
014-12270-12	CABINET REAR, TV, MOLDED PLASTIC, 3536V
020-04330-34	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03480	INSTR BOOK, OPERATION GUIDE

MODEL PARTS (Continued)

A-18639 CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 36V CTV
 A-18681-01 LINE CORD ASSY, WITH YEONHO CONNECTOR
 A-18695-04 GND STRAP ASSY, CRT
 F-52060 KEYBOARD ASSY, 10 POSITION

B36A30ZF

Part #	Description
009-02073	MODULE, MAIN, 36V STEREO CA CHASSIS, V-CHIP, PIP, 3 JACKS
009-02107	MODULE, SINGLE PIP, CA CHASSIS
012-10858-03	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12269-12	CABINET FRONT, TV, MOLDED PLASTIC, 35V-1R
014-12270-12	CABINET REAR, TV, MOLDED PLASTIC, 3536V
020-04330-34	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00229-01	SPACE COMMAND, TRANSMITTER, BIG BUTTON, MBR3346Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03480	INSTR BOOK, OPERATION GUIDE
206-03554	INSTR BOOK, OPERATION GUIDE
A-18639	CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 36V CTV
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-04	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B36A34Z0

Part #	Description
009-02076	MODULE, MAIN, 36V MTSSAP CA CHASSIS, V-CHIP, PIP, COMB FILT
009-02107	MODULE, SINGLE PIP, CA CHASSIS
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12269-12	CABINET FRONT, TV, MOLDED PLASTIC, 35V-1R
014-12270-12	CABINET REAR, TV, MOLDED PLASTIC, 3536V
020-04330-34	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233-01	SPACE COMMAND, TRANSMITTER, MBR3457Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03481	INSTR BOOK, OPERATION GUIDE
A-18639	CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 36V CTV
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-04	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B36A34Z6

Part #	Description
009-02076-01	MODULE, MAIN, 36V MTSSAP CA CHASSIS, V-CHIP, PIP, COMB FILT
009-02107	MODULE, SINGLE PIP, CA CHASSIS
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12269-12	CABINET FRONT, TV, MOLDED PLASTIC, 35V-1R
014-12270-12	CABINET REAR, TV, MOLDED PLASTIC, 3536V
020-04330-34	COIL, DEGAUSSER

030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233-01	SPACE COMMAND, TRANSMITTER, MBR3457Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03481	INSTR BOOK, OPERATION GUIDE
A-18639	CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 36V CTV
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-04	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

B36A34ZF

Part #	Description
009-02076	MODULE, MAIN, 36V MTSSAP CA CHASSIS, V-CHIP, PIP, COMB FILT
009-02107	MODULE, SINGLE PIP, CA CHASSIS
012-10858-04	MOLDED PLASTIC, PANEL, JACK PACK, CA CHASSIS
014-12269-12	CABINET FRONT, TV, MOLDED PLASTIC, 35V-1R
014-12270-12	CABINET REAR, TV, MOLDED PLASTIC, 3536V
020-04330-34	COIL, DEGAUSSER
030-01532	DECORATIVE ITEM, LOGO, ZENITH
049-01368-03	SPEAKER, OVAL, 6 X 13 CM
124-00233-01	SPACE COMMAND, TRANSMITTER, MBR3457Z
192-00912	LENS, PRIMARY CONTROLS AND IR
206-03481	INSTR BOOK, OPERATION GUIDE
206-03553	INSTR BOOK, OPERATION GUIDE
A-18639	CRT ASSEMBLY, WDEFLECTION YOKE AND BEAM BENDER, 36V CTV
A-18681-01	LINE CORD ASSY, WITH YEONHO CONNECTOR
A-18695-04	GND STRAP ASSY, CRT
F-52060	KEYBOARD ASSY, 10 POSITION

COMPONENT PARTS LIST REFERENCE CHART

Refer to the chart and Model Identifier to use the Component parts list.

Notes: The following information is for Models in and out of warranty.

Models 27" and below are Component level repair only.

Models 32" and above are Module level repair only. Module part numbers are listed in the Model Parts List in the beginning of this section.

To Order Parts: call 1-888-3-ZENITH
 fax 1-888-6-ZENITH

By Mail: ZENITH NATIONAL PARTS
 SALES AND DISTRIBUTION CENTER
 P O Box 240007
 Huntsville, AL 35824-6407

MODEL	IDENTIFIER
B25A02Z	A
B25A10Z	B
B25A10Z6	C
B25A10ZC	B
B25A10ZC6	C
B25A10ZCF	B
B25A11Z	D
B25A11Z6	E
B25A11ZF	D
B25A24Z	F
B25A24Z6	G
B25A24ZF	F
B25A30ZC	H
B25A30ZCF	H
B25A74R	I
B25A76R	I
B27A10Z	J
B27A10Z5	a
B27A10Z5	a
B27A10Z6	K
B27A10ZC	J
B27A10ZC5	a
B27A10ZC5	a
B27A10ZC6	K
B27A10ZCF	J
B27A11Z	L
B27A11Z5	M
B27A11Z6	N
B27A11Z65	O
B27A11ZC	L
B27A11ZC5	M
B27A24Z	P
B27A24Z5	Q
B27A24Z6	R
B27A24Z65	S
B27A24ZF	P
B27A24ZF5	Q
B27A30Z	T
B27A30ZC	T
B27A30ZC5	U
B27A30ZC6	V
B27A30ZC65	W
B27A30ZCF	T
B27A30ZCF5	U
B27A34Z	X
B27A34Z6	Y
B27A34ZF	X
B27A74R	Z
B27A74R5	Q
B27A76R	Z
B27A76R5	Q

MODEL	IDENTIFIER
CB25A25Z	F
CB25A25Z6	G
LGB26A11ZM	D
LGB26A11ZM6	E
LGB29A10ZM	J
LGB29A10ZM5	a
LGB29A10ZM5	a
LGB29A11ZM	L
LGB29A11ZM5	M
LGB29A13ZM	J
LGB29A24ZM	P
LGB29A24ZM5	Q
LGB29A30ZM	T
LGB29A30ZM5	U

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMNQRSTUUVWXYZa	2C5	050-01666-13	CONNECTOR&CABLE, ASSY, 2.5MM, 5 CONTACT, 2 UP
ABCDEFGHIJKLMNQRSTUUVWXYZa	2F5	050-01665-12	CONNECTOR&CABLE, ASSY, 2.5MM, 4 CONTACT, 2 UP
FGHILMNOPQRSTUVWXYZ	2K6	058-00526-05	PLUG, 0.098P 5 CONTACT
ABCDEFGHIJKLMNQRSTUUVWXYZa	3R8	058-00546-03	PLUG, MULTIPRONG, 3 POSITION
ABCDEFGHIJKLMNQRSTUUVWXYZa	3T8	058-00546-02	PLUG, MULTIPRONG, 2 POSITION
ABCDEFGHIJKLMNQRSTUUVWXYZa	3Y3	058-00546-04	PLUG, MULTIPRONG, 4 POSITION
ABCDEFGHIJKLMNQRSTUUVWXYZa	4G9	058-00526-05	PLUG, 0.098P 5 CONTACT
ABCDEFGHIJKLMNQRSTUUVWXYZa	9S4	058-00526-04	PLUG, 0.098P 4 CONTACT
ABCDEFGHIJKLMNQRSTUUVWXYZa	C0841	022-08310-16	CAP, 1000 MFD 20% 25V, ELECTRO
ABCDEFGHIJKLMNQRSTUUVWXYZa	C0842	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
ABCDEFGHIJKLMNQRSTUUVWXYZa	C0843	022-08310-12A	CAP, 100 MFD 20% 25V, ELECTRO
BCDEFGHIJKLMNQRSTUUVWXYZa	C0851	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNQRSTUUVWXYZa	C0852	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
ABCDEFGHIJKLMNQRSTUUVWXYZa	C0853	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
BCDEFGHIJKLMNQRSTUUVWXYZa	C0854	022-08310-16	CAP, 1000 MFD 20% 25V, ELECTRO
BCDEHJKLMNOTUVWa	C0855M	022-08366-16A	CAP, 4,700 PFD 10% 50V, CERAMIC CHIP, LDLESS
A	C0855M	022-08366-17A	CAP, 5,600 PFD 10% 50V, CERAMIC CHIP, LDLESS
FGIPQRSXYZ	C0855M	022-08366-18A	CAP, 6,800 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C0861	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNQRSTUUVWXYZa	C0862	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
ABCDEFGHIJKLMNQRSTUUVWXYZa	C0863	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
ABCDEFGHIJKLMNQRSTUUVWXYZa	C0864	022-08310-16	CAP, 1000 MFD 20% 25V, ELECTRO
BCDEHJKLMNOTUVWa	C0865M	022-08366-16A	CAP, 4,700 PFD 10% 50V, CERAMIC CHIP, LDLESS
A	C0865M	022-08366-17A	CAP, 5,600 PFD 10% 50V, CERAMIC CHIP, LDLESS
FGIPQRSXYV	C0865M	022-08366-18A	CAP, 6,800 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1200M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1201M	022-08366-08A	CAP, 1,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1202M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1203M	022-08366-08A	CAP, 1,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1204M	022-08366-08A	CAP, 1,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1205M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1206	022-08312-03A	CAP, 0.47 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1207	022-08312-03A	CAP, 0.47 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1208M	022-08370-24A	CAP, 22,000 PFD 10% 16V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1209M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1210	022-08309-13A	CAP, 220 MFD 20% 16V, ELECTRO

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1211M	022-08366-08A	CAP, 1,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1212	022-08312-03A	CAP, 0.47 MFD 20% 50V, ELECTRO
BCDEFGHIJKLMNQRSTUUVWXYZa	C1213M	022-08352-22A	CAP, 27 PFD 5% 50V, CERAMIC CHIP, LDLESS
A	C1213M	022-08366-16A	CAP, 4,700 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1214	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1215M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1216	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1217M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1218M	022-08352-38A	CAP, 120 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1219M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1220M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1221M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1222	022-08309-13A	CAP, 220 MFD 20% 16V, ELECTRO
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1223M	022-08366-08A	CAP, 1,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUUVWXYZa	C1224	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
FGIPQRSXYZ	C1401M	022-08370-22A	CAP, 15,000 PFD 10% 16V, CERAMIC CHIP, LDLESS
FGIPQRSXYZ	C1402M	022-08366-18A	CAP, 6,800 PFD 10% 50V, CERAMIC CHIP, LDLESS
FGIPQRSXYZ	C1403M	022-08370-22A	CAP, 15,000 PFD 10% 16V, CERAMIC CHIP, LDLESS
FGIPQRSXYZ	C1404M	022-08366-18A	CAP, 6,800 PFD 10% 50V, CERAMIC CHIP, LDLESS
FGIPQRSXYZ	C1406M	022-08370-24A	CAP, 22,000 PFD 10% 16V, CERAMIC CHIP, LDLESS
DEFGHILMNOPQRSTUVWXYZ	C1409	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
DEFGHILMNOPQRSTUVWXYZ	C1410	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
BCDEFGHIJKLMNQRSTUUVWXYZa	C1413	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
BCDEFGHIJKLMNQRSTUUVWXYZa	C1414	022-07669-15A	CAP, 10 MFD 10% 50V, ELECTRO
BCDEFGHIJKLMNQRSTUUVWXYZa	C1415	022-08312-04A	CAP, 1 MFD 20% 50V, ELECTRO
BCDEFGHIJKLMNQRSTUUVWXYZa	C1416	022-08188-05A	CAP, 10 MFD 20% 25V, NONPLZD ELECTROLYTIC
BCDEFGHIJKLMNQRSTUUVWXYZa	C1417	022-08188-05A	CAP, 10 MFD 20% 25V, NONPLZD ELECTROLYTIC
BCDEFGHIJKLMNQRSTUUVWXYZa	C1418	022-08312-04A	CAP, 1 MFD 20% 50V, ELECTRO
BCDEFGHIJKLMNQRSTUUVWXYZa	C1419	022-07669-14A	CAP, 3.3 MFD 10% 50V, ELECTRO
BCDEFGHIJKLMNQRSTUUVWXYZa	C1420	022-08049-13A	CAP, 0.012 MFD 10% 50V, POLYESTER
BCDEFGHIJKLMNQRSTUUVWXYZa	C1421	022-08257-21A	CAP, 5600 PFD 10% 50V, CERAMIC DISC
BCDEFGHIJKLMNQRSTUUVWXYZa	C1422	022-08049-20A	CAP, 0.047 MFD 10% 50V, POLYESTER
BCDEHJKLMNOTUVWa	C1423	022-08312-04A	CAP, 1 MFD 20% 50V, ELECTRO
BCDEFGHIJKLMNQRSTUUVWXYZa	C1424	022-08257-17A	CAP, 2700 PFD 10% 50V, CERAMIC DISC
FGIPQRSXYZ	C1425	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
FGIPQRSXYZ	C1426	022-08188-05A	CAP, 10 MFD 20% 25V, NONPLZD ELECTROLYTIC
BCDEFGHIJKLMNQPQRSTUVWXYZa	C1427	022-08188-05A	CAP, 10 MFD 20% 25V, NONPLZD ELECTROLYTIC
BCDEFGHIJKLMNQPQRSTUVWXYZa	C1428	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
BCDEHJKLMNQTUVW	C1429	022-08312-05A	CAP, 2.2 MFD 20% 50V, ELECTRO
BCDEFGHIJKLMNQPQRSTUVWXYZa	C1430	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
FGIPQRSXYZ	C1431M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
FGIPQRSXYZ	C1432	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
BCDEFGHIJKLMNQPQRSTUVWXYZa	C1433M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
BCDEFGHIJKLMNQPQRSTUVWXYZa	C1436	022-08312-04A	CAP, 1 MFD 20% 50V, ELECTRO
BCDEHJKLMNQTUVW	C1437	022-08312-05A	CAP, 2.2 MFD 20% 50V, ELECTRO
BCDEHJKLMNQTUVW	C1438	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
BCDEHJKLMNQTUVW	C1439	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
FGIPQRSXYZ	C1440	022-08309-14A	CAP, 330 MFD 20% 16V, ELECTRO
FGIPQRSXYZ	C1441M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
FGIPQRSXYZ	C1442	022-08309-11A	CAP, 4.7 MFD 20% 16V, ELECTRO
FGIPQRSXYZ	C1443	022-08312-03A	CAP, 0.47 MFD 20% 50V, ELECTRO
FGIPQRSXYZ	C1444M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
FGIPQRSXYZ	C1445	022-08309-11A	CAP, 4.7 MFD 20% 16V, ELECTRO
FGIPQRSXYZ	C1446	022-08312-03A	CAP, 0.47 MFD 20% 50V, ELECTRO
DEHLMNQTUVW	C1455	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
DEHLMNQTUVW	C1456	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2101	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2102	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2103	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2104	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2106	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2108	022-08310-11A	CAP, 4.7 MFD 20% 25V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2109	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2111	022-07786C	CAP, 1000 PFD 10% 500V, CERAMIC DISC
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2112	022-07786-10C	CAP, 470 PFD 10% 500V, CERAMIC DISC
ABCDEFHIJKLMNQPQRZa	C2201M	063-11059-09A	RESISTOR, THICK FILM CHIP, 22 OHM 5% 1/10W
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2202M	022-08352-14A	CAP, 12 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2203	022-08312A	CAP, 0.1 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2204	022-08312A	CAP, 0.1 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2205	022-08312A	CAP, 0.1 MFD 20% 50V, ELECTRO

RC	REF	PART#	DESCRIPTION
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2206M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2207	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2208	022-08312-05A	CAP, 2.2 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2209	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2210M	022-08370-24A	CAP, 22,000 PFD 10% 16V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2213M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2214M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2215M	022-08366-04A	CAP, 470 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2216	022-08312-04A	CAP, 1 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2217M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2218	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2219	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2220	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2221	022-08312A	CAP, 0.1 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2222	022-08312A	CAP, 0.1 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2223	022-08312-04A	CAP, 1 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2224	022-08492-01A	CAP, 1 MFD 20% 50V, NONPLZD ELECTROLYTIC
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2225	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2226	022-08312-04A	CAP, 1 MFD 20% 50V, ELECTRO
FGIPQRSXYZ	C2227	022-08310-11A	CAP, 4.7 MFD 20% 25V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2229M	022-08354-41A	CAP, 160 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2230	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2231	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2232M	022-08352-22A	CAP, 27 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2235M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2236M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2237M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2238M	022-08366-08A	CAP, 1,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
HTUVWXY	C2239	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFHIJKLMNQPQRSTUVWXYZa	C2241	022-08310-10A	CAP, 33 MFD 20% 25V, ELECTRO
HTUVW	C2242M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFHIJKLMNQPQRZa	C2242M	022-08352-38A	CAP, 120 PFD 5% 50V, CERAMIC CHIP, LDLESS
MOQSUW	C2254	022-07786-11C	CAP, 560 PFD 10% 500V, CERAMIC DISC
ABCDEFHIJKLMNPRVXYZ	C2254	022-08048-01A	CAP, 0.0012 MFD 5% 50V, POLYESTER
HTUVWXY	C2501M	022-08352-31A	CAP, 62 PFD 5% 50V, CERAMIC CHIP, LDLESS
HTUVWXY	C2502	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
HTUVWXY	C2504	022-08309-11A	CAP, 47 MFD 20% 16V, ELECTRO
HTUVWXY	C2505	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
HTUVWXY	C2506	022-08309-11A	CAP, 47 MFD 20% 16V, ELECTRO
HTUVWXY	C2507M	022-08366-20	CAP, 10,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
HTUVWXY	C2508	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
HTUVWXY	C2509M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
HTUVWXY	C2510M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
HTUVWXY	C2511	022-08312A	CAP, 0.1 MFD 20% 50V, ELECTRO
HTUVWXY	C2512M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
HTUVWXY	C2513	022-08312-01A	CAP, 0.22 MFD 20% 50V, ELECTRO
HTUVWXY	C2514M	022-08366-20	CAP, 10,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
HTUVWXY	C2515	022-08310-11A	CAP, 47 MFD 20% 25V, ELECTRO
HTUVWXY	C2516M	022-08366-28	CAP, 47,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
HTUVWXY	C2517	022-08312-01A	CAP, 0.22 MFD 20% 50V, ELECTRO
HTUVWXY	C2518M	022-08352-14A	CAP, 12 PFD 5% 50V, CERAMIC CHIP, LDLESS
HTUVWXY	C2519M	022-08352-38A	CAP, 120 PFD 5% 50V, CERAMIC CHIP, LDLESS
HTUVWXY	C2520M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
HTUVWXY	C2521M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
HTUVWXY	C2522M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
HTUVWXY	C2524	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
HTUVWXY	C2526	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
HTUVWXY	C2527	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
HTUVWXY	C2529M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
HTUVWXY	C2530	022-08312-03A	CAP, 0.47 MFD 20% 50V, ELECTRO
HTUVWXY	C2531	022-08048-01A	CAP, 0.0012 MFD 5% 50V, POLYESTER
HTUVWXY	C2532	022-08247-46A	CAP, 330 PFD 5% 50V, CERAMIC DISC
HTUVWXY	C2534M	022-08366-08A	CAP, 1,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
HTUVWXY	C2536M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
FGHIPQRSTUWVXYZ	C2900	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
FGHIPQRSTUWVXYZ	C2904	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
FGIPQRSXYZ	C2906	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
FGIPQRSXYZ	C2907M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
HTUVWXY	C2908	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
HTUVWXY	C2909	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
XY	C2910	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO

RC	REF	PART#	DESCRIPTION
HTUVWXY	C2911	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
XY	C2912M	022-08352-31A	CAP, 62 PFD 5% 50V, CERAMIC CHIP, LDLESS
XY	C2913	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
XY	C2914	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
XY	C2916	022-08257-24A	CAP, 10,000 PFD 10% 50V, CERAMIC DISC
XY	C2917M	022-08352-31A	CAP, 62 PFD 5% 50V, CERAMIC CHIP, LDLESS
HTUVWXY	C2918	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
FGIPQRSXYZ	C2919	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNQRSTUWVXYZa	C3201M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUWVXYZa	C3202	022-08257-08A	CAP, 470 PFD 10% 50V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWVXYZa	C3203	022-08049-16A	CAP, 0.022 MFD 10% 50V, POLYESTER
ABCDEFGHIJKLMNQRSTUWVXYZa	C3204	022-07786-17C	CAP, 2200 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWVXYZa	C3206	022-07811A	CAP, 1000 PFD 10% 1000V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWVXYZa	C3209	022-07786-10C	CAP, 470 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWVXYZa	C3419	022-07786-10C	CAP, 470 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWVXYZa	C3421	022-07786-10C	CAP, 470 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWVXYZa	C3425	022-08310-15	CAP, 470 MFD 20% 25V, ELECTRO
ABCDEFGHIJKLMNQRSTUWVXYZa	C3426	022-08309-13A	CAP, 220 MFD 20% 16V, ELECTRO
ABCDEFGHIJKLMNQRSTUWVXYZa	C3429	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
ABCDEFGHIJKLMNQRSTUWVXYZa	C3460	022-08310-13A	CAP, 220 MFD 20% 25V, ELECTRO
ABCDEFGHIJKLMNQRSTUWVXYZa	C5101	022-08318-04A	CAP, 1 MFD 20% 350V, ELECTRO
ABCDEFGHIJKLMNQRSTUWVXYZa	C5102M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUWVXYZa	C5103M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUWVXYZa	C5104	022-07523-01B	CAP, 0.01 MFD +80 % & -20 % 2000V, CERAMIC DI
ABCDEFGHIJKLMNQRSTUWVXYZa	C5105M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUWVXYZa	C5106M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUWVXYZa	C5107	022-08309-13A	CAP, 220 MFD 20% 16V, ELECTRO
ABCDEFGHIJKLMNQRSTUWVXYZa	C5108M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUWVXYZa	C5109M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUWVXYZa	C5110	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
ABCDEFGHIJKLMNQRSTUWVXYZa	C5111	022-07786-10C	CAP, 470 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWVXYZa	C6001M	022-08352-38A	CAP, 120 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNQRSTUWVXYZa	C6003M	022-08366-04A	CAP, 470 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEJKa	C6004	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNQRSTUWVXYZa	C6005M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6006	022-08312-04A	CAP, 1 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6007M	022-08366-08A	CAP, 1,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6009	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6010M	022-08352-19A	CAP, 20 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6011M	022-08352-19A	CAP, 20 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6012M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6013	022-08309-13A	CAP, 220 MFD 20% 16V, ELECTRO
ABCDEJLMNOa	C6014M	022-08352-22A	CAP, 27 PFD 5% 50V, CERAMIC CHIP, LDLESS
FGHIPQRSTUVWXYZ	C6014M	022-08352-32A	CAP, 68 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEJLMNOa	C6015M	022-08352-22A	CAP, 27 PFD 5% 50V, CERAMIC CHIP, LDLESS
FGHIPQRSTUVWXYZ	C6015M	022-08352-32A	CAP, 68 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6016	022-08312-05A	CAP, 2.2 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6017	022-08049-24A	CAP, 0.10 MFD 10% 50V, POLYESTER
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6018M	022-08366-12A	CAP, 2,200 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6019M	022-08366-04A	CAP, 470 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6020	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6021M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSXYZa	C6023M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
HTUVW	C6023M	022-08354-41A	CAP, 160 PFD 5% 50V, CERAMIC CHIP, LDLESS
CEGKNORSVWY	C6026M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6028	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6029M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
CEGKNORSVWY	C6030	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
ABDFHIJLMPQTUXZa	C6030	022-08309-16	CAP, 1000 MFD 20% 16V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6031M	022-08366-12A	CAP, 2,200 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6032	022-08312-04A	CAP, 1 MFD 20% 50V, ELECTRO
FGGILMNOPQRSTUVWXYZ	C6036M	022-08366-08A	CAP, 1,000 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6037	022-08257-04A	CAP, 220 PFD 10% 50V, CERAMIC DISC
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6038M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6040M	022-08352-38A	CAP, 120 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6041M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6042M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6043M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6045M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6046M	022-08366-04A	CAP, 470 PFD 10% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6047M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6048M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6049M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6050M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6051M	022-08354-41A	CAP, 160 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6052M	022-08354-41A	CAP, 160 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6053M	022-08354-41A	CAP, 160 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6055M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6056M	022-08368-20A	CAP, 10,000 PFD 10% 25V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6058M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6061M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
XY	C6064M	022-08366A	CAP, 220 PFD 10% 50V, CERAMIC CHIP, LDLESS
XY	C6065M	022-08352-19A	CAP, 20 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6068M	022-08366-12A	CAP, 2,200 PFD 10% 50V, CERAMIC CHIP, LDLESS
CEGKNORSVWY	C6069M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
CEGKNORSVWY	C6070M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6079M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6090M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6092M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6093M	022-08352-31A	CAP, 62 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6094M	022-08352-31A	CAP, 62 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6095M	022-08352-28A	CAP, 47 PFD 5% 50V, CERAMIC CHIP, LDLESS
ABCDEFGHIJKLMNPQRSTUVWXYZa	C6098	022-08312-07A	CAP, 4.7 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	CR2201	224-00027A	CRYSTAL, QUARTZ, 3.579 MHZ
ABCDEFGHIJKLMNPQRSTUVWXYZa	CR2202	224-00178	RESONATOR, CERAMIC, 503 KHZ
HTUVWXY	CR2501	224-00061-04	CRYSTAL, QUARTZ, 14.31818 MHZ
ABCDEFGHIJKLMNPQRSTUVWXYZa	CRT0001	078-03394-09	SOCKET, CRT
ABCDEFGHIJKLMNPQRSTUVWXYZa	CRY6001	224-00074-02A	CRYSTAL, QUARTZ, 8 MHZ
ABCDEFGHIJKLMNPQRSTUVWXYZa	CX2105	022-08311-13	CAP, 220 MFD 20% 35V, ELECTRO
XY	CX2107	022-08310-16	CAP, 1000 MFD 20% 25V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	CX2107	022-08310-17	CAP, 2200 MFD 20% 25V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	CX2110	022-08311-12A	CAP, 100 MFD 20% 35V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	CX3003	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	CX3004	022-08312-08A	CAP, 10 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	CX3007	022-07786-10C	CAP, 470 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNPQRSTUVWXYZa	CX3205	022-08309-12A	CAP, 100 MFD 20% 16V, ELECTRO
ABCDEFGHIJKLMNPQRSTUVWXYZa	CX3207A	022-08159	CAP, 0.68 MFD 10% 200V, POLYESTER



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMNQRSTUWXYZa	CX3208	022-08317-08	CAP, 10 MFD 20% 250V, ELECTRO
MOQSUWa	CX3210	022-08386-01	CAP, 270 PFD 10% 2000V, CERAMIC DISC
XY	CX3211	022-08386-08	CAP, 1000 PFD 10% 2000V, CERAMIC DISC
JKLMNOPQRSTUWZa	CX3212	022-08386-05	CAP, 560 PFD 10% 2000V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3215	022-07786-10C	CAP, 470 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3216	022-08229-27	CAP, 0.013 MFD 3% 1600VDC, POLYPROPYLENE
XY	CX3217	022-08231-11	CAP, 0.39 MFD 5% 200V, POLYPROPYLENE
JKLNPRVTZ	CX3217	022-08231-12	CAP, 0.47 MFD 5% 200V, POLYPROPYLENE
ABCDEFGHI	CX3217	022-08231-13	CAP, 0.56 MFD 5% 200V, POLYPROPYLENE
MOQSUWa	CX3217	091-02053	WIRE, SOLID, BARE, 22 GA COPPER
ABCDEFGHIJKLMNQRSTUWXYZa	CX3218	022-08315-05A	CAP, 2.2 MFD 20% 160V, ELECTRO
JKLMNOPQRSTUWZa	CX3219	022-08227-04A	CAP, 0.022 MFD 5% 50V, POLYESTER
MOQSUWa	CX3251	091-02053	WIRE, SOLID, BARE, 22 GA COPPER
ABCDEFGHIJKLMNQRSTUWXYZa	CX3253	022-08312-11A	CAP, 47 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNQRSTUWXYZa	CX3254	022-07786-10C	CAP, 470 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3400	022-07431-06B	CAP, 0.0047 MFD 20%, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3401	022-07867-10	CAP, 0.1 MFD 20% 250VAC, POLYESTER
ABCDEFGHIJKLMNQRSTUWXYZa	CX3402	022-07431-06B	CAP, 0.0047 MFD 20%, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3403	022-07811A	CAP, 1000 PFD 10% 1000V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3404	022-07811A	CAP, 1000 PFD 10% 1000V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3405	022-07811A	CAP, 1000 PFD 10% 1000V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3406	022-07811A	CAP, 1000 PFD 10% 1000V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3407	022-08444-09	CAP, 330 MFD 20% 200V, ELECTRO
ABCDEFGHIJKLMNQRSTUWXYZa	CX3408	022-07786-10C	CAP, 470 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3409	022-08386-08	CAP, 1000 PFD 10% 2000V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3410	022-07786C	CAP, 1000 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3411	022-08049-18A	CAP, 0.033 MFD 10% 50V, POLYESTER
ABCDEFGHIJKLMNQRSTUWXYZa	CX3412	022-07786C	CAP, 1000 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3413	022-08312-09A	CAP, 22 MFD 20% 50V, ELECTRO
ABCDEFGHIJKLMNQRSTUWXYZa	CX3415	022-08008-12	CAP, .01 MFD 5% 1250V, POLYPROPYLENE
ABCDEFGHIJKLMNQRSTUWXYZa	CX3416	022-08310-12A	CAP, 100 MFD 20% 25V, ELECTRO
ABCDEFGHIJKLMNQRSTUWXYZa	CX3418	022-07786-01C	CAP, 220 PFD 10% 500V, CERAMIC DISC
ABCDEFGHIJKLMNQRSTUWXYZa	CX3420	022-08444-07	CAP, 220 MFD 20% 200V, ELECTRO
ABCDEFGHIJKLMNQRSTUWXYZa	CX3424	022-08310-16	CAP, 1000 MFD 20% 25V, ELECTRO
ABCDEFGHIJKLMNQRSTUWXYZa	CX3430	022-08310-15	CAP, 470 MFD 20% 25V, ELECTRO
CEGKNORSVWY	CX6027	022-08309-15A	CAP, 470 MFD 20% 16V, ELECTRO

RC	REF	PART#	DESCRIPTION
BCDEHJKLNMOTUVWa	D1401	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUWXYZa	D2201	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUWXYZa	D2202	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUWXYZa	D2203	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUWXYZa	D2204	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUWXYZa	D2205	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
XY	D2207	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
XY	D2208	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
XY	D2209	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
HTUVWXY	D2210	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
HTUVWXY	D2211	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
HTUVWXY	D2212	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
HTUVWXY	D2501	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
HTUVWXY	D2502	103-00347-03A	DIODE, LOW VOLTAGE GENERAL, SILICON
ABCDEFGHIJKLMNQRSTUWXYZa	D3410	103-00589	DIODE, FAST RECOVERY RECTIFIER, 400 PIV
ABCDEFGHIJKLMNQRSTUWXYZa	D3411	103-00589	DIODE, FAST RECOVERY RECTIFIER, 400 PIV
ABCDEFGHIJKLMNQRSTUWXYZa	D5101	103-00279-04A	DIODE, ZENER, 3V 0.5W
ABCDEFGHIJKLMNQRSTUWXYZa	D5102	103-00344-06A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUWXYZa	D6001	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUWXYZa	D6002	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUWXYZa	DAG0000	A-19197	GROUNDING ASSY , WIRE AND TERMINAL, WHITE, DAG
ABCDEFGHIJKLMNQRSTUWXYZa	DAG0001	A-19197	GROUNDING ASSY , WIRE AND TERMINAL, WHITE, DAG
FGIPQRSXYV	DL2200	223-00045	INTD CKT PKG, NTSC COMB FILTER, HYBRID
ABCDEFGHIJKLMNQRSTUWXYZa	DX2101	103-00347-03A	DIODE, LOW VOLTAGE GENERAL, SILICON
ABCDEFGHIJKLMNQRSTUWXYZa	DX2102	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUWXYZa	DX2103	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUWXYZa	DX2104	103-00339-04A	DIODE, LOW VOLTAGE GENERAL, SILICON



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3005	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3006	103-00344-06A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3201	103-00344-06A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3203	103-00347-03A	DIODE, LOW VOLTAGE GENERAL, SILICON
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3204	103-00461A	DIODE, ULTRA FAST SWITCHING, HIGH CONDUCTANCE
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3252	103-00344-06A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3401	103-00588A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3402	103-00588A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3403	103-00588A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3404	103-00588A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3405	103-00347-03A	DIODE, LOW VOLTAGE GENERAL, SILICON
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3406	103-00344-06A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3407	103-00344-06A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUUVWXYz	DX3408	103-00344-06A	DIODE, LOW VOLTAGE GENERAL
ABCDEFGHIJKLMNQRSTUUVWXYz	EX3401	038-00102	SPARK GAP, HIGH VOLTAGE, 4KV DC
IZ	FX3401	136-00114-23A	FUSE, NORMAL LAG, 4 AMP 250V
ABCDEFGHIJKLMNQRSTUUVWXYz	FX3401	136-00114-23C	FUSE, NORMAL LAG, 4 AMP 250V
IZ	FX3402	136-00148-23	FUSE, NORMAL LAG, 3 AMP 250V
ABCDEFGHIJKLMNQRSTUUVWXYz	FX3402	136-00148-23C	FUSE, NORMAL LAG, 3 AMP 250V
ABCDEFGHIJKLMNQRSTUUVWXYz	IC0804	126-03700	HEAT SINK, IC, AUDIO AMPLIFIER
ABCDEFGHIJKLMNQRSTUUVWXYz	IC0804	221-00598-01	INTEGRATED CKT, AUDIO POWER AMP
FGIPQRSXYZ	IC1400	221-01127	INTEGRATED CKT, MTS STEREO DECODER/VOL.LIMITER AND
BCDEHJKLMNOTUVWz	IC1400	221-01382	INTEGRATED CKT, AUDIO MULTIPLEXING DECODER, USA
DEHLMNOTUVW	IC1401	221-01171	INTEGRATED CKT, AUDIO/VIDEO SWITCH, 2 CHAN/2 POSIT
BCDEHJKLMNOTUVWz	IC1402	221-01380	INTEGRATED CKT, STEREO AMP, AND DC VOL/CONTROL
Z	IC2100	126-03626	HEAT SINK, TRANSISTOR, HORIZONTAL OUTPUT
ABCDEFGHIJKLMNQRSTUUVWXYz	IC2100	126-03626-04	HEAT SINK, TRANSISTOR, HORIZONTAL OUTPUT
ABCDEFGHIJKLMNQRSTUUVWXYz	IC2100	221-00992-01	INTEGRATED CKT, VERTICAL DEFLECTION
HTUVWXY	IC2501	221-01393	INTEGRATED CKT, Y/C PIP CONTROLLER
HTUVWXY	IC2502	221-01183	INTEGRATED CKT, ANALOG MULTIPLEX/DEMULTIPLEX, TRIP
FGHIPQRSTUUVWXYZ	IC2901	221-01171	INTEGRATED CKT, AUDIO/VIDEO SWITCH, 2 CHAN/2 POSIT
HTUVWXY	IC2902	221-01171	INTEGRATED CKT, AUDIO/VIDEO SWITCH, 2 CHAN/2 POSIT
ABCDEFGHIJKLMNQRSTUUVWXYz	IC6000	126-03446-02	SHIELD, EMI, MICROPROCESSOR
BCDEJKLMNOz	IC6000	221-01384-01	INTEGRATED CKT, 8-BIT MICROCOMPUTER
AFGIPQRSZ	IC6000	221-01384-02	INTEGRATED CKT, 8-BIT MICROCOMPUTER
HTUVW	IC6000	221-01386-01	INTEGRATED CKT, 8-BIT MICROCOMPUTER
XY	IC6000	221-01387-01	INTEGRATED CKT, 8-BIT MICROCOMPUTER

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMNQRSTUUVWXYz	IC6001	221-00745-04	INTEGRATED CKT, 4K BIT SERIAL EEPROM
ABCDEFGHIJKLMNQRSTUUVWXYz	IC6002	221-01177A	INTEGRATED CKT, SYSTEM RESET
ABCDEFGHIJKLMNQRSTUUVWXYz	ICX2200	221-01165	INTEGRATED CKT, I2C BUS CONTROL NTSC
ABCDEFGHIJKLMNQRSTUUVWXYz	ICX3400	126-03660-01	HEATSINK, TRANSISTOR
ABCDEFGHIJKLMNQRSTUUVWXYz	ICX3400	223-00028	INTD CKT PKG, HYBRID, VOLTAGE REGULATOR
ABCDEFGHIJKLMNQRSTUUVWXYz	ICX3401	126-03326-02	HEATSINK, TRANSISTOR
ABCDEFGHIJKLMNQRSTUUVWXYz	ICX3401	221-00213-09	INTEGRATED CKT, 9 VOLT, 1 AMP, LINEAR, REGULATOR
ABCDEFGHIJKLMNQRSTUUVWXYz	ICX3402	126-02131-01	HEAT SINK, TRANSISTOR
ABCDEFGHIJKLMNQRSTUUVWXYz	ICX3402	221-00213	INTEGRATED CKT, 5 VOLT, 1 AMP, LINEAR, REGULATOR
ABCDEJKz	IR6000	012-10795	BRACKET, IR DETECTOR MOUNTING
ABCDEJKz	IR6000	162-00046	IR DETECTOR
FGIPQRSXYZ	J0001	A-18785-02	JACK ASSEMBLY, 5 PHONO/1 Y-C
DEHLMNOTUVW	J0001	A-18785-03	JACK ASSEMBLY, AV, 3 PHONO
ABCDEFGHIJKLMNQRSTUUVWXYz	J0003M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYz	J0006M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYz	J0007M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYz	J0008M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYz	J0009M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYz	J0010M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYz	J0012M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYz	J0015M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
BCJKz	J1406M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
BCJKz	J1407M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSz	J2201M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSz	J2202M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
HTUVWXY	J2501M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
HTUVWXY	J2502M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
HTUVWXY	J2504M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
HTUVWXY	J2510M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
HTUVWXY	J2512M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
BCDEHJKLMNOTUVWz	J2902M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYz	KX3401	195-00161	RELAY, SPST, 12 VDC COIL
ABCDEFGHIJKLMNQRSTUUVWXYz	L1200	020-03907-25A	COIL, 120 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMNQRSTUUVWXYz	L1201	020-04277-09A	COIL, 0.82 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMNQRSTUUVWXYz	L1202	020-04278B	COIL, RCF, TUNABLE, 7.0 MM
ABCDEFGHIJKLMNQRSTUUVWXYz	L1203	020-03907-12A	COIL, 10 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMNQRSTUUVWXYz	L1204	020-04277-39A	COIL, 10 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMNQRSTUUVWXYz	L1205	020-04277-23A	COIL, 12 MICROHENRY, RCF, FIXED



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMN	L1206	020-04506A	COIL, RCF, FIXED, SHIELDED
ABCDEFGHIJKLMN	L1207	020-04277-23A	COIL, 12 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMN	L2201	020-04129-22	COIL, 15 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMN	L2202	020-04129-16	COIL, 4.7 MICROHENRY, RCF, FIXED
HTUVWXY	L2501	091-02053	WIRE, SOLID, BARE, 22 GA COPPER
HTUVWXY	L2502	020-03907-12A	COIL, 10 MICROHENRY, RCF, FIXED
HTUVWXY	L2503	020-03907-12A	COIL, 10 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMN	L3405	020-04462-18A	COIL, 33 MICROHENRY, RCF, FIXED
HTUVWXY	L3407	020-03907-21A	COIL, 56 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMN	L3407	020-03907-24A	COIL, 100 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMN	L5101	020-03907-28A	COIL, 220 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMN	L5102	063-10246-46	RESISTOR, FILM, 1.2M OHM 10% 1/2W
ABCDEFGHIJKLMN	L5103	149-00583-01	CORE, FERRITE BEAD
CEGNORSVWY	L6000	020-03907-24A	COIL, 100 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMN	L6001	020-04129-16	COIL, 4.7 MICROHENRY, RCF, FIXED
FGHIJKLMNOPQ	L6002	020-04277-10A	COIL, 1.0 MICROHENRY, RCF, FIXED
ABCDEJKLMNO	L6002	020-04277-20A	COIL, 6.8 MICROHENRY, RCF, FIXED
ABCDEFGHIJKLMN	L6003	020-04129-08	COIL, 1 MICROHENRY, RCF, FIXED
FGHILMNOPQR	L6004	020-04129-08	COIL, 1 MICROHENRY, RCF, FIXED
FGHILMNOPQR	L6005	020-04129-08	COIL, 1 MICROHENRY, RCF, FIXED
ABCDEJK	L6005	091-02053	WIRE, SOLID, BARE, 22 GA COPPER
ABCDEFGHIJKLMN	L6007	020-04129-16	COIL, 4.7 MICROHENRY, RCF, FIXED
MOQSUW	LX3201	022-08231-10	CAP, 0.33 MFD 5% 200V, POLYPROPYLENE
ABCDEFGHIJKLMN	LX3202	149-00540-01	CORE, FERRITE
ABCDEFGHIJKLMN	LX3262	020-04073-03	COIL, RCF
ABCDEFGHIJKLMN	LX3401	095-04593	TRANSFORMER, LINE CHOKE
ABCDEFGHIJKLMN	LX3403	149-00540-01	CORE, FERRITE
ABCDEFGHIJKLMN	LX3404	149-00540-01	CORE, FERRITE
ABCDEFGHIJKLMN	LX3410	149-00549	CORE, FERRITE, WITH CAPTIVATED THRU-LEAD
HTUVWXY	PIP	009-02107	MODULE, SINGLE PIP, CA CHASSIS
HTUVWXY	PIPA	058-00605-10	PLUG, MULTIPRONG, 10 POSITION
HTUVWXY	PIPB	058-00605-10	PLUG, MULTIPRONG, 10 POSITION
ABCDEFGHIJKLMN	Q0800	121-01310A	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q1200	121-01261A	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q1201	121-01310A	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q1202	121-01310A	TRANSISTOR, NPN, SILICON
FGIPQRSXYZ	Q1401	121-01310A	TRANSISTOR, NPN, SILICON
FGIPQRSXYZ	Q1402	121-01310A	TRANSISTOR, NPN, SILICON
FGIPQRSXYZ	Q1403	121-01310A	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q2201	121-01311A	TRANSISTOR, PNP, SILICON
ABCDEFGHIJKLMN	Q2202	121-01311A	TRANSISTOR, PNP, SILICON
ABCDEFGHIJKLMN	Q2203	121-01311A	TRANSISTOR, PNP, SILICON
ABCDEFGHIJKLMN	Q2204	121-01310A	TRANSISTOR, NPN, SILICON

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMN	Q2205	121-01311A	TRANSISTOR, PNP, SILICON
ABCDEFGHIJKLMN	Q2206	121-01311A	TRANSISTOR, PNP, SILICON
XY	Q2207	121-01390	TRANSISTOR, NPN, SILICON
ABCDEHJKLMNOTUV	Q2208	121-01311A	TRANSISTOR, PNP, SILICON
ABCDEFGHIJKLMN	Q2209	121-01311A	TRANSISTOR, PNP, SILICON
HTUVWXY	Q2210	121-01391A	TRANSISTOR, PNP, SILICON
HTUVWXY	Q2501	121-01310A	TRANSISTOR, NPN, SILICON
HTUVWXY	Q2502	121-01310A	TRANSISTOR, NPN, SILICON
HTUVWXY	Q2503	121-01310A	TRANSISTOR, NPN, SILICON
HTUVWXY	Q2504	121-01310A	TRANSISTOR, NPN, SILICON
HTUVWXY	Q2505	121-01311A	TRANSISTOR, PNP, SILICON
XY	Q2902	121-01311A	TRANSISTOR, PNP, SILICON
ABCDEFGHIJKLMN	Q3201	121-01310A	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q3202	121-01264-01A	TRANSISTOR, NPN SILICON
ABCDEFGHIJKLMN	Q3402	121-01340A	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q3403	121-01340A	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q3404	121-01102A	TRANSISTOR, PNP, SILICON
ABCDEFGHIJKLMN	Q5101	121-01291-01	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q5102	121-01291-01	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q5103	121-01291-01	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q5104	121-01140A	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q6001	121-01310A	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	Q6002	121-01310A	TRANSISTOR, NPN, SILICON
XY	Q6003	121-01390	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	QX3203	121-01383	TRANSISTOR, NPN, SILICON
ABCDEFGHIJKLMN	QX3203	126-03626-01	HEAT SINK, TRANSISTOR, HORIZONTAL OUTPUT
ABCDEFGHIJKLMN	QX3401	121-01348	TRANSISTOR, NPN, SILICON, 80V/1A
ABCDEFGHIJKLMN	R0843	063-10235-60	RESISTOR, FILM, 330 OHM 5% 1/4W
FGIPQRSXYZ	R0851M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
BCDEHJKLMNOTUV	R0851M	063-11059-89A	RESISTOR, THICK FILM CHIP, 47K OHM 5% 1/10W
BCDEFGHIJKLMN	R0852M	063-11059-57A	RESISTOR, THICK FILM CHIP, 2.2K OHM 5% 1/10W
ABCDEFGHIJKLMN	R0853	063-10235-12	RESISTOR, FILM, 3.3 OHM 5% 1/4W
ABCDEFGHIJKLMN	R0854M	063-11059-29A	RESISTOR, THICK FILM CHIP, 150 OHM 5% 1/10W
FGIPQRSXYZ	R0861M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
A	R0861M	063-11059-76A	RESISTOR, THICK FILM CHIP, 13K OHM 5% 1/10W
BCDEHJKLMNOTUV	R0861M	063-11059-89A	RESISTOR, THICK FILM CHIP, 47K OHM 5% 1/10W
BCDEFGHIJKLMN	R0862M	063-11059-57A	RESISTOR, THICK FILM CHIP, 2.2K OHM 5% 1/10W
A	R0862M	063-11059-59A	RESISTOR, THICK FILM CHIP, 2.7K OHM 5% 1/10W
ABCDEFGHIJKLMN	R0863	063-10235-12	RESISTOR, FILM, 3.3 OHM 5% 1/4W
ABCDEFGHIJKLMN	R0864M	063-11059-29A	RESISTOR, THICK FILM CHIP, 150 OHM 5% 1/10W
CEGNORSVWY	R1200M	063-11059-97A	RESISTOR, THICK FILM CHIP, 100K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1201M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1202M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1203M	063-11059-39A	RESISTOR, THICK FILM CHIP, 390 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1204M	063-11059-53A	RESISTOR, THICK FILM CHIP, 1.5K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1205M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMN	R1206M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1207M	063-11059-09A	RESISTOR, THICK FILM CHIP, 22 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1208M	063-11059-09A	RESISTOR, THICK FILM CHIP, 22 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1209M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1210M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1211M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1212M	063-11059-61A	RESISTOR, THICK FILM CHIP, 3.3K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1213M	063-11059-46A	RESISTOR, THICK FILM CHIP, 750 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1214M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1215M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1216M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1217M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1218M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1219M	063-11059-29A	RESISTOR, THICK FILM CHIP, 150 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1220M	063-11059-29A	RESISTOR, THICK FILM CHIP, 150 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1221M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
ABCDEFGHIJKLMN	R1222M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1223M	063-11059-97A	RESISTOR, THICK FILM CHIP, 100K OHM 5% 1/10W
ABCDEFGHIJKLMN	R1224M	063-11059-87A	RESISTOR, THICK FILM CHIP, 39K OHM 5% 1/10W
ABDFHIJLMPTUXZa	R1225	063-10235-98	RESISTOR, FILM, 12K OHM 5% 1/4W
BCDEFGHIJKLMN	R1401	063-10235-48	RESISTOR, FILM, 100 OHM 5% 1/4W
BCDEFGHIJKLMN	R1402	063-10235-48	RESISTOR, FILM, 100 OHM 5% 1/4W
BCDEFGHIJKLMN	R1404M	063-11244-76A	RESISTOR, THICK FILM CHIP, 61.9K OHM 1% 1/10W
BCDEFGHIJKLMN	R1405M	063-11059-61A	RESISTOR, THICK FILM CHIP, 3.3K OHM 5% 1/10W
BCDEFGHIJKLMN	R1406M	063-11059-97A	RESISTOR, THICK FILM CHIP, 100K OHM 5% 1/10W
BCDEFGHIJKLMN	R1407M	063-11059-60A	RESISTOR, THICK FILM CHIP, 3K OHM 5% 1/10W
BCDEFGHIJKLMN	R1408M	063-11059-61A	RESISTOR, THICK FILM CHIP, 3.3K OHM 5% 1/10W
FGIPQRSXYZ	R1409M	063-11060-21A	RESISTOR, THICK FILM CHIP, 1 MEG OHM 5% 1/10W
DEHLMN	R1412	063-10235-74	RESISTOR, FILM, 1.2K OHM 5% 1/4W
FGIPQRSXYZ	R1412	063-10235-80	RESISTOR, FILM, 2.2K OHM 5% 1/4W
DEHLMN	R1413	063-10235-74	RESISTOR, FILM, 1.2K OHM 5% 1/4W
FGIPQRSXYZ	R1413	063-10235-80	RESISTOR, FILM, 2.2K OHM 5% 1/4W
DEHLMN	R1416	063-10235-94	RESISTOR, FILM, 8.2K OHM 5% 1/4W
BCDEHJKLMN	R1417	063-10243-56	RESISTOR, FILM, 220 OHM 5% 1/2W
BCDEHJKLMN	R1418M	063-11059-57A	RESISTOR, THICK FILM CHIP, 2.2K OHM 5% 1/10W

RC	REF	PART#	DESCRIPTION
BCDEHJKLMN	R1420M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
BCDEFGHIJKLMN	R1421M	063-11059-71A	RESISTOR, THICK FILM CHIP, 8.2K OHM 5% 1/10W
BCDEFGHIJKLMN	R1422M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
BCDEFGHIJKLMN	R1425M	063-11060-21A	RESISTOR, THICK FILM CHIP, 1 MEG OHM 5% 1/10W
FGIPQRSXYZ	R1440M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
FGIPQRSXYZ	R1441M	063-11059-97A	RESISTOR, THICK FILM CHIP, 100K OHM 5% 1/10W
FGIPQRSXYZ	R1442M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
FGIPQRSXYZ	R1443M	063-11059-41A	RESISTOR, THICK FILM CHIP, 470 OHM 5% 1/10W
FGIPQRSXYZ	R1444M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
FGIPQRSXYZ	R1445M	063-11059-37A	RESISTOR, THICK FILM CHIP, 330 OHM 5% 1/10W
FGIPQRSXYZ	R1446	063-10235-68	RESISTOR, FILM, 680 OHM 5% 1/4W
FGIPQRSXYZ	R1447M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
FGIPQRSXYZ	R1448M	063-11059-41A	RESISTOR, THICK FILM CHIP, 470 OHM 5% 1/10W
FGIPQRSXYZ	R1449M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
FGIPQRSXYZ	R1450M	063-11059-37A	RESISTOR, THICK FILM CHIP, 330 OHM 5% 1/10W
FGIPQRSXYZ	R1451	063-10235-68	RESISTOR, FILM, 680 OHM 5% 1/4W
ABCDEFGHIJKLMN	R2101	063-10235-72	RESISTOR, FILM, 1K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2102M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2103	063-10235-96	RESISTOR, FILM, 10K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2104	063-10236-26	RESISTOR, FILM, 180K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2105	063-10236-24	RESISTOR, FILM, 150K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2106	063-10236-41	RESISTOR, FILM, 750K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2107M	063-11059-89A	RESISTOR, THICK FILM CHIP, 47K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2108	063-10236-10	RESISTOR, FILM, 39K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2109M	063-11059-77A	RESISTOR, THICK FILM CHIP, 15K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2110M	063-11059-77A	RESISTOR, THICK FILM CHIP, 15K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2111M	063-11059-89A	RESISTOR, THICK FILM CHIP, 47K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2112M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHI	R2113	063-10235-84	RESISTOR, FILM, 3.3K OHM 5% 1/4 W
JKLMNOPQRSTU	R2113	063-10235-86	RESISTOR, FILM, 3.9K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2114	063-10235-90	RESISTOR, FILM, 5.6K OHM 5% 1/4W
XY	R2114	063-10235-92	RESISTOR, FILM, 6.8K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2118	063-10565-61	RESISTOR, FILM, 360 OHM 5% 1/2W
ABCDEFGHIJKLMN	R2119	063-10565-61	RESISTOR, FILM, 360 OHM 5% 1/2W
ABCDEFGHIJKLMN	R2120M	063-11059-39A	RESISTOR, THICK FILM CHIP, 390 OHM 5% 1/10W



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMN	R2121	063-10235-94	RESISTOR, FILM, 8.2K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2122	063-10235-88	RESISTOR, FILM, 4.7K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2123M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
XY	R2201M	063-11059-27A	RESISTOR, THICK FILM CHIP, 120 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2201M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2202M	063-11059-47A	RESISTOR, THICK FILM CHIP, 820 OHM 5% 1/10W
a	R2202M	063-11059A	RESISTOR/ THICK FILM CHIP/ 0 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2203M	063-11059-60A	RESISTOR, THICK FILM CHIP, 3K OHM 5% 1/10W
XY	R2203M	063-11059-61A	RESISTOR, THICK FILM CHIP, 3.3K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2204M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2205M	063-11059-60A	RESISTOR, THICK FILM CHIP, 3K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2206M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2207M	063-11059-60A	RESISTOR, THICK FILM CHIP, 3K OHM 5% 1/10W
XY	R2207M	063-11059-61A	RESISTOR, THICK FILM CHIP, 3.3K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2208M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2209M	063-11059-47A	RESISTOR, THICK FILM CHIP, 820 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2210M	063-10235-66	RESISTOR, FILM, 560 OHM 5% 1/4W
JKLMN	R2211M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIXY	R2211M	063-11059-53A	RESISTOR, THICK FILM CHIP, 1.5K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2212M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2213M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2214M	063-11059-83A	RESISTOR, THICK FILM CHIP, 27K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2215M	063-11059-47A	RESISTOR, THICK FILM CHIP, 820 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2216	063-10235-24	RESISTOR, FILM, 10 OHM 5% 1/4W
JKLMN	R2217M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIXY	R2217M	063-11059-53A	RESISTOR, THICK FILM CHIP, 1.5K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2218M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2219M	063-11059-47A	RESISTOR, THICK FILM CHIP, 820 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2220	063-10235-48	RESISTOR, FILM, 100 OHM 5% 1/4W
JKLMN	R2221M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIXY	R2221M	063-11059-53A	RESISTOR, THICK FILM CHIP, 1.5K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2222M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2223	063-10235-48	RESISTOR, FILM, 100 OHM 5% 1/4W
ABCDEFGHIJKLMN	R2224M	063-11059-77A	RESISTOR, THICK FILM CHIP, 15K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2225M	063-11059-61A	RESISTOR, THICK FILM CHIP, 3.3K OHM 5% 1/10W

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMN	R2226	063-10235-88	RESISTOR, FILM, 4.7K OHM 5% 1/4W
ABCDEFGHIJKLMN	R2227M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2228	063-10235-64	RESISTOR, FILM, 470 OHM 5% 1/4W
ABCDEFGHIJKLMN	R2229M	063-11059-57A	RESISTOR, THICK FILM CHIP, 2.2K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2230M	063-11059-97A	RESISTOR, THICK FILM CHIP, 100K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2231M	063-11059-39A	RESISTOR, THICK FILM CHIP, 390 OHM 5% 1/10W
ABCDEFGHI	R2232M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
JKLMN	R2232M	063-11059-53A	RESISTOR, THICK FILM CHIP, 1.5K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2233	063-10235-48	RESISTOR, FILM, 100 OHM 5% 1/4W
ABCDEFGHIJKLMN	R2234M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
JKLMN	R2235	063-10243-74	RESISTOR, FILM, 1.2K OHM 5% 1/2W
ABCDEFGHI	R2235	063-10243-79	RESISTOR, FILM, 2K OHM 5% 1/2W
ABCDEFGHIJKLMN	R2236M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2237M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2238M	063-11059-53A	RESISTOR, THICK FILM CHIP, 1.5K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2239M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2240M	063-11059-46A	RESISTOR, THICK FILM CHIP, 750 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2241M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2242M	063-11060-13A	RESISTOR, THICK FILM CHIP, 470K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2243M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2244M	063-11059-97A	RESISTOR, THICK FILM CHIP, 100K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2245M	063-11059-17A	RESISTOR, THICK FILM CHIP, 47 OHM 5% 1/10W
FGIPQRSXYZ	R2246M	063-11059-83A	RESISTOR, THICK FILM CHIP, 27K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2247M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
FGIPQRSXYZ	R2248M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2249M	063-11059-29A	RESISTOR, THICK FILM CHIP, 150 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2250M	063-11059-29A	RESISTOR, THICK FILM CHIP, 150 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2251	063-10235-48	RESISTOR, FILM, 100 OHM 5% 1/4W
ABCDEFGHIJKLMN	R2252M	063-11059-87A	RESISTOR, THICK FILM CHIP, 39K OHM 5% 1/10W
ABCDEFGHIJKLMN	R2254M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
XY	R2255	063-10235-60	RESISTOR, FILM, 330 OHM 5% 1/4W
XY	R2256M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
XY	R2257M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
XY	R2258M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
ABCDEFGHIJKLMN	R2259M	063-11059-39A	RESISTOR, THICK FILM CHIP, 390 OHM 5% 1/10W



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMNOTUVW	R2260M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
ABCDEFGHIJKLMNOTUVW	R2261M	063-11059-29A	RESISTOR, THICK FILM CHIP, 150 OHM 5% 1/10W
ABCDEFGHIJKLMNOTUVW	R2262M	063-11059-29A	RESISTOR, THICK FILM CHIP, 150 OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYZa	R2263	063-10236-32	RESISTOR, FILM, 330K OHM 5% 1/4W
ABCDEFGHIJKLMNQRSTUUVWXYZa	R2264	063-10236-44	RESISTOR, FILM, 1M OHM 5% 1/4W
ABCDEFGHIJKLMNQRSTUUVWXYZa	R2265M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
	R2265M	063-11059-73A	RESISTOR/ THICK FILM CHIP/ 10K OHM 5% 1/10W
HTUVVWXY	R2266	063-10235-64	RESISTOR, FILM, 470 OHM 5% 1/4W
HTUVVWXY	R2267M	063-11059-83A	RESISTOR, THICK FILM CHIP, 27K OHM 5% 1/10W
HTUVVWXY	R2268M	063-11059-97A	RESISTOR, THICK FILM CHIP, 100K OHM 5% 1/10W
ABCDEJLKMNOa	R2269M	063-11059-09A	RESISTOR, THICK FILM CHIP, 22 OHM 5% 1/10W
FGHIPQRSTUVWZ	R2269M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
HTUVVWXY	R2501M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
HTUVVWXY	R2502M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
HTUVVWXY	R2504M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
HTUVVWXY	R2505M	063-11059-35A	RESISTOR, THICK FILM CHIP, 270 OHM 5% 1/10W
HTUVVWXY	R2507M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
HTUVVWXY	R2508M	063-11059-77A	RESISTOR, THICK FILM CHIP, 15K OHM 5% 1/10W
HTUVVWXY	R2509M	063-11060-61A	RESISTOR, THICK FILM CHIP, 4.7M OHM 5% 1/10W
HTUVVWXY	R2510M	063-11059-37A	RESISTOR, THICK FILM CHIP, 330 OHM 5% 1/10W
HTUVVWXY	R2511M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
HTUVVWXY	R2512M	063-11059-37A	RESISTOR, THICK FILM CHIP, 330 OHM 5% 1/10W
HTUVVWXY	R2513M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
HTUVVWXY	R2516M	063-11059-41A	RESISTOR, THICK FILM CHIP, 470 OHM 5% 1/10W
HTUVVWXY	R2517M	063-11059-41A	RESISTOR, THICK FILM CHIP, 470 OHM 5% 1/10W
HTUVVWXY	R2518M	063-11059-41A	RESISTOR, THICK FILM CHIP, 470 OHM 5% 1/10W
HTUVVWXY	R2519M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
HTUVVWXY	R2520	063-10235-72	RESISTOR, FILM, 1K OHM 5% 1/4W
HTUVVWXY	R2521M	063-11059-37A	RESISTOR, THICK FILM CHIP, 330 OHM 5% 1/10W
HTUVVWXY	R2523M	063-11059-57A	RESISTOR, THICK FILM CHIP, 2.2K OHM 5% 1/10W
HTUVVWXY	R2524M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
HTUVVWXY	R2525M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
HTUVVWXY	R2529	063-10235-64	RESISTOR, FILM, 470 OHM 5% 1/4W
HTUVVWXY	R2530M	063-11059-84A	RESISTOR, THICK FILM CHIP, 30K OHM 5% 1/10W
HTUVVWXY	R2531M	063-11060-04A	RESISTOR, THICK FILM CHIP, 200K OHM 5% 1/10W

RC	REF	PART#	DESCRIPTION
HTUVVWXY	R2532M	063-11059-51A	RESISTOR, THICK FILM CHIP, 1.2K OHM 5% 1/10W
HTUVVWXY	R2533M	063-11059-59A	RESISTOR, THICK FILM CHIP, 2.7K OHM 5% 1/10W
HTUVVWXY	R2534	063-10235-48	RESISTOR, FILM, 100 OHM 5% 1/4W
HTUVVWXY	R2535	063-10235-48	RESISTOR, FILM, 100 OHM 5% 1/4W
HTUVVWXY	R2539M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
HTUVVWXY	R2540M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
HTUVVWXY	R2541M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
HTUVVWXY	R2542M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
HTUVVWXY	R2543M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
HTUVVWXY	R2544M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
HTUVVWXY	R2545	063-10235-96	RESISTOR, FILM, 10K OHM 5% 1/4W
HTUVVWXY	R2546M	063-11059-75A	RESISTOR, THICK FILM CHIP, 12K OHM 5% 1/10W
HTUVVWXY	R2547M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
HTUVVWXY	R2549	063-10565-12	RESISTOR, FILM, 3.3 OHM 5% 1/2W
FGHIPQRSTUUVWXYZ	R2901M	063-11059-71A	RESISTOR, THICK FILM CHIP, 8.2K OHM 5% 1/10W
FGHIPQRSTUUVWXYZ	R2902M	063-11059-57A	RESISTOR, THICK FILM CHIP, 2.2K OHM 5% 1/10W
FGIPQRSXYZ	R2907	063-10235-72	RESISTOR, FILM, 1K OHM 5% 1/4W
FGIPQRSXYZ	R2908	063-10235-40	RESISTOR, FILM, 47 OHM 5% 1/4W
FGIPQRSXYZ	R2909	063-10235-83	RESISTOR, FILM, 3K OHM 5% 1/4W
FGIPQRSXYZ	R2910M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
FGIPQRSXYZ	R2911	063-10235-45	RESISTOR, FILM, 75 OHM 5% 1/4W
FGIPQRSXYZ	R2912	063-10235-45	RESISTOR, FILM, 75 OHM 5% 1/4W
DEFGHILMNOPQRSTUUVWXYZ	R2914	063-10235-40	RESISTOR, FILM, 47 OHM 5% 1/4W
HTUVVWXY	R2915M	063-11059-71A	RESISTOR, THICK FILM CHIP, 8.2K OHM 5% 1/10W
DEFGHILMNOPQRSTUUVWXYZ	R2916	063-10235-45	RESISTOR, FILM, 75 OHM 5% 1/4W
HTUVVW	R2917M	063-11059-60A	RESISTOR, THICK FILM CHIP, 3K OHM 5% 1/10W
XY	R2917M	063-11059-61A	RESISTOR, THICK FILM CHIP, 3.3K OHM 5% 1/10W
XY	R2918M	063-11059-60A	RESISTOR, THICK FILM CHIP, 3K OHM 5% 1/10W
XY	R2919M	063-11059-41A	RESISTOR, THICK FILM CHIP, 470 OHM 5% 1/10W
XY	R2920M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
XY	R2921M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
XY	R2922M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
XY	R2923M	063-11059-51A	RESISTOR, THICK FILM CHIP, 1.2K OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYZa	R3201M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
ABCDEFGHIJKLMNQRSTUUVWXYZa	R3202M	063-11059-29A	RESISTOR, THICK FILM CHIP, 150 OHM 5% 1/10W



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMN	R3203	063-11087-64	RESISTOR, FILM, 470 OHM 5% 1/2W
ABCDEFGHIJKLMN	R3204	063-11087-66	RESISTOR, FILM, 560 OHM 5% 1/2W
ABCDEFGHIJKLMN	R3205	063-11087-66	RESISTOR, FILM, 560 OHM 5% 1/2W
ABCDEFGHIJKLMN	R3412M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R3414	063-10235-80	RESISTOR, FILM, 2.2K OHM 5% 1/4W
ABCDEFGHIJKLMN	R3418	063-10235-88	RESISTOR, FILM, 4.7K OHM 5% 1/4W
ABCDEFGHIJKLMN	R3419	063-10235-88	RESISTOR, FILM, 4.7K OHM 5% 1/4W
ABCDEFGHIJKLMN	R3440	063-10243-48	RESISTOR, FILM, 100 OHM 5% 1/2W
ABCDEFGHIJKLMN	R5101M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R5102M	063-11059-17A	RESISTOR, THICK FILM CHIP, 47 OHM 5% 1/10W
ABCDEFGHIJKLMN	R5103	063-10244-22	RESISTOR, FILM, 120K OHM 5% 1/2W
ABCDEFGHIJKLMN	R5105M	063-11059-27A	RESISTOR, THICK FILM CHIP, 120 OHM 5% 1/10W
ABCDEFGHIJKLMN	R5106M	063-11059-17A	RESISTOR, THICK FILM CHIP, 47 OHM 5% 1/10W
ABCDEFGHIJKLMN	R5107	063-10243-72	RESISTOR, FILM, 1K OHM 5% 1/2W
ABCDEFGHIJKLMN	R5108M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R5109M	063-11059-17A	RESISTOR, THICK FILM CHIP, 47 OHM 5% 1/10W
ABCDEFGHIJKLMN	R5110	063-10244-22	RESISTOR, FILM, 120K OHM 5% 1/2W
ABCDEFGHIJKLMN	R5112M	063-11059-27A	RESISTOR, THICK FILM CHIP, 120 OHM 5% 1/10W
ABCDEFGHIJKLMN	R5113M	063-11059-17A	RESISTOR, THICK FILM CHIP, 47 OHM 5% 1/10W
ABCDEFGHIJKLMN	R5114	063-10235-64	RESISTOR, FILM, 470 OHM 5% 1/4W
ABCDEFGHIJKLMN	R5115	063-10243-72	RESISTOR, FILM, 1K OHM 5% 1/2W
ABCDEFGHIJKLMN	R5116	063-10243-72	RESISTOR, FILM, 1K OHM 5% 1/2W
ABCDEFGHIJKLMN	R5117M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R5118M	063-11059-17A	RESISTOR, THICK FILM CHIP, 47 OHM 5% 1/10W
ABCDEFGHIJKLMN	R5119	063-10244-22	RESISTOR, FILM, 120K OHM 5% 1/2W
ABCDEFGHIJKLMN	R5120M	063-11059-27A	RESISTOR, THICK FILM CHIP, 120 OHM 5% 1/10W
ABCDEFGHIJKLMN	R5121M	063-11059-17A	RESISTOR, THICK FILM CHIP, 47 OHM 5% 1/10W
ABCDEFGHIJKLMN	R5123	063-10243-72	RESISTOR, FILM, 1K OHM 5% 1/2W
ABCDEFGHIJKLMN	R5124M	063-11059-71A	RESISTOR, THICK FILM CHIP, 8.2K OHM 5% 1/10W
ABCDEFGHIJKLMN	R5125	063-10235-72	RESISTOR, FILM, 1K OHM 5% 1/4W
ABCDEFGHIJKLMN	R5126	063-10244-28	RESISTOR, FILM, 220K OHM 5% 1/2W
ABCDEFGHIJKLMN	R5127	063-10243-72	RESISTOR, FILM, 1K OHM 5% 1/2W
ABCDEFGHIJKLMN	R6001M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
ABCDEFGHIJKLMN	R6002M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
ABCDEFGHIJKLMN	R6003M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMN	R6004M	063-11059-89A	RESISTOR, THICK FILM CHIP, 47K OHM 5% 1/10W
ABCDEFGHIJKLMN	R6005M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
ABCDEFGHIJKLMN	R6006M	063-11059-29A	RESISTOR, THICK FILM CHIP, 150 OHM 5% 1/10W
ABCDEFGHIJKLMN	R6008M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R6012	063-10236-12	RESISTOR, FILM, 47K OHM 5% 1/4W
ABCDEFGHIJKLMN	R6015	063-10235-72	RESISTOR, FILM, 1K OHM 5% 1/4W
ABCDEFGHIJKLMN	R6016	063-10235-72	RESISTOR, FILM, 1K OHM 5% 1/4W
ABCDEJKa	R6017M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEJKa	R6018	063-10235-96	RESISTOR, FILM, 10K OHM 5% 1/4W
ABCDEJKa	R6019M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEJKa	R6020M	063-11059-56A	RESISTOR, THICK FILM CHIP, 2K OHM 5% 1/10W
a	R6021	063-10235-72	RESISTOR/ FILM/ 1K OHM 5% 1/4W
ABCDEJK	R6021M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEJKa	R6022M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEJKa	R6023M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEJKa	R6024M	063-11059-56A	RESISTOR, THICK FILM CHIP, 2K OHM 5% 1/10W
ABCDEJKa	R6025M	063-11059-56A	RESISTOR, THICK FILM CHIP, 2K OHM 5% 1/10W
ABCDEFGHIJKLMN	R6026	063-10235-96	RESISTOR, FILM, 10K OHM 5% 1/4W
ABCDEFGHIJKLMN	R6027	063-10235-80	RESISTOR, FILM, 2.2K OHM 5% 1/4W
ABCDEJKa	R6028	063-10235-60	RESISTOR, FILM, 330 OHM 5% 1/4W
ABCDEJKa	R6029M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMN	R6030	091-02053	WIRE, SOLID, BARE, 22 GA COPPER
ABCDEFGHIJKLMN	R6031M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHIJKLMN	R6032M	063-11059-77A	RESISTOR, THICK FILM CHIP, 15K OHM 5% 1/10W
ABCDEFGHIJKLMN	R6033M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMN	R6034M	063-11060-21A	RESISTOR, THICK FILM CHIP, 1 MEG OHM 5% 1/10W
ABCDEFGHIJKLMN	R6035M	063-11060-21A	RESISTOR, THICK FILM CHIP, 1 MEG OHM 5% 1/10W
ABCDEFGHIJKLMN	R6036M	063-11059A	RESISTOR, THICK FILM CHIP, 0 OHM 5% 1/10W
ABCDEFGHIJKLMN	R6037M	063-11059-83A	RESISTOR, THICK FILM CHIP, 27K OHM 5% 1/10W
ABCDEFGHIJKLMN	R6039M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
XY	R6040M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
ABCDEFGHIJKLMN	R6041	063-10235-56	RESISTOR, FILM, 220 OHM 5% 1/4W
ABCDEFGHIJKLMN	R6042M	063-11059-37A	RESISTOR, THICK FILM CHIP, 330 OHM 5% 1/10W
ABCDEFGHIJKLMN	R6043	063-10235-56	RESISTOR, FILM, 220 OHM 5% 1/4W
ABCDEFGHIJKLMN	R6044M	063-11059-37A	RESISTOR, THICK FILM CHIP, 330 OHM 5% 1/10W



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

COMPONENT PARTS LIST

SEE REFERENCE CHART ON PAGE 4-12

RC	REF	PART#	DESCRIPTION
BCDEJKLMOa	R6045M	063-11059-57A	RESISTOR, THICK FILM CHIP, 2.2K OHM 5% 1/10W
A	R6045M	063-11059-61A	RESISTOR, THICK FILM CHIP, 3.3K OHM 5% 1/10W
FGHIPQRSTUVWXYZ	R6045M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
BCDEJKLMOa	R6046M	063-11059-56A	RESISTOR, THICK FILM CHIP, 2K OHM 5% 1/10W
A	R6046M	063-11059-61A	RESISTOR, THICK FILM CHIP, 3.3K OHM 5% 1/10W
FGHIPQRSTUVWXYZ	R6046M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6047M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6048M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6049	063-10235-56	RESISTOR, FILM, 220 OHM 5% 1/4W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6050M	063-11059-33A	RESISTOR, THICK FILM CHIP, 220 OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6053M	063-11059-53A	RESISTOR, THICK FILM CHIP, 1.5K OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6058M	063-11059-87A	RESISTOR, THICK FILM CHIP, 39K OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6059M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6060M	063-11059-65A	RESISTOR, THICK FILM CHIP, 4.7K OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6061M	063-11059-57A	RESISTOR, THICK FILM CHIP, 2.2K OHM 5% 1/10W
FGHILMNPPQRSTUVWXYZ	R6069M	063-11060-13A	RESISTOR, THICK FILM CHIP, 470K OHM 5% 1/10W
FGHILMNPPQRSTUVWXYZ	R6070M	063-11060-13A	RESISTOR, THICK FILM CHIP, 470K OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6072	063-10235-96	RESISTOR, FILM, 10K OHM 5% 1/4W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6080	063-10236-41	RESISTOR, FILM, 750K OHM 5% 1/4W
HTUVWXY	R6082M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSZa	R6082M	063-11059-41A	RESISTOR, THICK FILM CHIP, 470 OHM 5% 1/10W
XY	R6083M	063-11059-60A	RESISTOR, THICK FILM CHIP, 3K OHM 5% 1/10W
XY	R6084M	063-11059-73A	RESISTOR, THICK FILM CHIP, 10K OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	R6090M	063-11059-49A	RESISTOR, THICK FILM CHIP, 1K OHM 5% 1/10W
ABCDEFGHI	RX2115	063-11110-04	RESISTOR, FILM, 1.5 OHM 5% 1/2W
JKLMNPPQRSTUVWXYZa	RX2115	063-11110-06	RESISTOR, FILM, 1.8 OHM 5% 1/2W
ABCDEFGHI	RX2116	063-11110-04	RESISTOR, FILM, 1.5 OHM 5% 1/2W
JKLMNPPQRSTUVWXYZa	RX2116	063-11110-06	RESISTOR, FILM, 1.8 OHM 5% 1/2W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX2117	063-10235-10	RESISTOR, FILM, 2.7 OHM 5% 1/4W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX2124	063-11214-16	RESISTOR, FILM, 0.51 OHM 5% 1/2W
HTUVWXY	RX2503	091-02053	WIRE, SOLID, BARE, 22 GA COPPER
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3008	063-10936-37	RESISTOR, FILM, 2.21K OHM 1% 1/4W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3009M	063-11059-97A	RESISTOR, THICK FILM CHIP, 100K OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3010M	063-11059-25A	RESISTOR, THICK FILM CHIP, 100 OHM 5% 1/10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3016	063-10936-72	RESISTOR, FILM, 4.32K OHM 1% 1/4W

RC	REF	PART#	DESCRIPTION
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3022	063-10936-72	RESISTOR, FILM, 4.32K OHM 1% 1/4W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3207	063-10243-45	RESISTOR, FILM, 75 OHM 5% 1/2W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3208	063-10565-10	RESISTOR, FILM, 2.7 OHM 5% 1/2W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3209	063-10460-44A	RESISTOR, WIREWOUND, 6.8 OHM 10% 10W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3211	063-10565	RESISTOR, FILM, 1 OHM 5% 12W
ABCDEFGHIXY	RX3212	063-10235-88	RESISTOR, FILM, 4.7K OHM 5% 14W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3214	063-10244-04	RESISTOR, FILM, 22K OHM 5% 12W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3215	063-10832-69B	RESISTOR, FILM, 750 OHM 5% 1W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3216	063-11160-60B	RESISTOR, FILM, 330 OHM 5% 2W
JKLNPRTVZ	RX3217	063-10442-28A	RESISTOR, WIREWOUND, 1.5 OHM 5% 5W
ABCDEFGHI	RX3217	063-10442-37A	RESISTOR, WIREWOUND, 3.6 OHM 5% 5W
MOQSUWa	RX3217	063-11164-02B	RESISTOR, FILM, 1.2 OHM 5% 3W
XY	RX3217	063-11164-10B	RESISTOR, FILM, 2.7 OHM 5% 3W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3218	063-10243-48	RESISTOR, FILM, 100 OHM 5% 1/2W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3400	063-11264-01	RESISTOR, CARBON COMPOSITION, 5.6M OHM 20% 1/2W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3401	063-10444-20A	RESISTOR, WIREWOUND, 0.68 OHM 10% 5W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3403	063-10442-04A	RESISTOR, WIREWOUND, 0.15 OHM 5% 5 WATT
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3404	063-11088-26	RESISTOR, FILM, 180K OHM 5% 1/2W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3405	063-11164-02B	RESISTOR, FILM, 1.2 OHM 5% 3W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3406	063-10235-40	RESISTOR, FILM, 47 OHM 5% 1/4W
IZ	RX3407	063-11156-40B	RESISTOR, FILM, 47 OHM 5% 1W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3407	063-11160-35B	RESISTOR, FILM, 30 OHM 5% 2W
IZ	RX3408	063-11156-32B	RESISTOR, FILM, 22 OHM 5% 1W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3408	063-11160-24B	RESISTOR, FILM, 10 OHM 5% 2W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3409	063-10565-28	RESISTOR, FILM, 15 OHM 5% 1/2W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX3417	063-10444-52B	RESISTOR, WIREWOUND, 15 OHM 10% 5 WATT
K	RX3423	063-11160-48B	RESISTOR, FILM, 100 OHM 5% 2W
ABCDEFGHIJKLMNPPQRSZa	RX3423	063-11160-52B	RESISTOR, FILM, 150 OHM 5% 2W
HTUVWXY	RX3427	063-10442-60B	RESISTOR, WIREWOUND, 33 OHM 5% 5W
K	RX3427	063-11160-48B	RESISTOR, FILM, 100 OHM 5% 2W
ABCDEFGHIJKLMNPPQRSZa	RX3427	063-11160-52B	RESISTOR, FILM, 150 OHM 5% 2W
ABCDEHJKLMNPPQRSZa	RX3428	063-10235-54	RESISTOR, FILM, 180 OHM 5% 1/4W
FGIPQRSXYZ	RX3428	063-10243-45	RESISTOR, FILM, 75 OHM 5% 1/2W
ABCDEFGHIJKLMNPPQRSTUVWXYZa	RX5104	063-10837B	RESISTOR, FILM, 15K OHM 5% 2W



Critical safety components are identified by the letter "X" in their component designators and are shaded. Replace only with part numbers specified.

zenith 